


CONTENTS

CONTENTS

- Part I Instrument overview 2
- Part II Main screen 2
- Part III How to 3
 - 1. Calibrate the instrument 3
 - 2. Select parameters and related tolerances 4
 - 3. Perform the measurement 5
 - 4. Display measurement results 10
 - 5. Change language 11
 - 6. Enable - disable bluetooth 12

PART I INSTRUMENT OVERVIEW



PART II MAIN SCREEN

In the figure you can see a typical instrument screen after the switch-on sequence:




Figure 1. Main screen.

Much of the screen is used, depending on the level we're on, by the measurement parameters list or by the menu items or by options list.

To the right side there are some system icons that are always displayed in every screen: respectively from the top there is the battery level icon, the bluetooth status icon and the profile save mode icon.

If in the screen there is a vertical scrolling menu list, to the lower right side the related scrolling indicator, represented by two little overlapped triangles, is displayed: if the upper triangle becomes grey it means that we are at the beginning of the list, whereas if the lower triangle becomes grey it means that we reached the end of the list.

PART III HOW TO

1. CALIBRATE THE INSTRUMENT

To go to the calibration screen press  to enter main menu, then press repeatedly  until you reach the **Calibration** item and finally press  to confirm.




Figure 2. Roughness calibration screen.

You have to perform the following steps:

1. **Insert the nominal value:** move with  to the box with numerical value, inside the box move to the desired digit with  then press  until you reach the desired value.
2. **Start measure:** after setting the nominal value press  to move to **start measure** item then press  to confirm.

2. SELECT PARAMETERS AND RELATED TOLERANCES

To go to the parameters selection screen press  to enter main menu, then press repeatedly  until you reach **Parameters** item and finally press  to confirm.

We'll get the following screen:



Figure 3. Parameters selection list screen.

Parameters selected for being displayed are those marked by  icon, whereas those not selected are marked by the  icon.

To go to the parameters options setting screen move to the desired parameter with  then confirm by pressing .

We'll get the following screen:



Figure 4. Parameter options setting screen.

To enable / disable the parameter move to the  icon with  then press .

To enable / disable the tolerance check move with  to the little box on the left marked by the label **Tol** then press .

To set the upper and lower tolerance limits values move with  to reach the numeric boxes, then keep moving with  inside them to reach the desired position of the digit whose value you want to change and finally press  until you reach the desired value.

Press then  to return to main menu.

3. PERFORM THE MEASUREMENT

To verify that all the measurement parameters are correct go from main menu through  to the relative setting screen by selecting the item **Set measure** and pressing  to confirm.

We'll get the following screen:




Figure 5. measurement parameters setting screen.

1. **Measurement standard selection.** move with  to the item **Stand-**
ard then press  to confirm.
 The following screen is displayed:




Figure 6. measurement standard setting screen.

move to the desired item with  then confirm by pressing . If you select the standard **ISO 4287** it is also possible to select the measurement unit; also in this case you move to the item to be activated with  and confirm by pressing . Press then  to return to the setting screen.

2. **Cut-off length selection** (standard ISO 4287). Move with  to the **Cut-off L.** item then press  to confirm.
 The following screen is displayed:



Figure 7. cut-off length setting window.

Move to the desired item with  then confirm by pressing .
 The currently selected value is represented with a larger size than the other values.

Press then  to return to setting screen.

3. **Cut-off number selection** (standard ISO 4287). Move with  to the item **Cut-off No.** then press  to confirm.

The following screen is displayed:




Figure 8. cut-off length setting screen.

Move to the desired item with  then confirm by pressing  . The currently selected value is represented with a larger size than the other values.

Press then  to return to setting screen.

4. **Measurement length selection** (standard ISO 12085). Move with  to the item **Meas L.** then press  to confirm.

The following screen is displayed:




Figure 9. measurement length setting screen.

Move to the desired item with  then confirm by pressing  .
The currently selected value is represented with a larger size than the other values.

Press then  to return to setting screen.

5. **Start measure delay selection.** Move with  to the item **Delay**

then press  to confirm.

The following screen is displayed:



Figure 10. start measure delay setting screen.

Move to the desired item with  then confirm by pressing  .
The currently selected value is indicated by the cursor position at the bottom .

Press then  to return to setting screen.

6. **End of measurement automatic return selection.** Move with  to

the item **Return** then press  to confirm.

The following screen is displayed:



Figure 11. End of measure automatic return mode setting screen.

Move to the desired item with  then confirm by pressing  .
Press then  to return to main menu.

To verify the correct positioning of the pickup tip move from main menu with  to the appropriate control screen by selecting **Position** and pressing  to confirm.

We'll get the following screen:



Figure 12. pickup tip position display screen.

Press  to start the measurement.

Press  to return to setting screen.

When all the operations are completed press  to return to starting screen

then press again  to start the measurement.

4. DISPLAY MEASUREMENT RESULTS

the measure results screen is automatically displayed at the end of the measure. If the measure results have been already loaded in memory and we are in a different

screen, press repeatedly on  until you reach the measure results screen.

If only one parameter has been enabled, the following screen will be displayed:



Figure 13. One parameter screen.

If two parameters have been enabled, the following screen will be displayed:



Figure 14. Two parameters screen.

If three or more parameters have been enabled, the following screen will be displayed:




Figura 15. Three or more parameters screen.

5. CHANGE LANGUAGE

To go to the language selection screen press  to enter main menu, then press repeatedly  until you reach the item **System** then press  to confirm.

We'll get the following screen:



Figure 15. system settings menu screen.

To go to the language selection screen press  until you reach the item **Language** then press  to confirm.

We'll get the following screen:



Figure 16. language setting screen.

press repeatedly  until you reach the desired language then press  to confirm.

At the end press  twice to return to main menu.

6. ENABLE - DISABLE BLUETOOTH

To go the bluetooth connection activation screen press  to enter main menu, then press repeatedly  until you reach the item **System** then press  to confirm.

We'll get the following screen:



Figure 15. system settings menu screen.

To enable/disable bluetooth press  until you reach the item **Bluetooth** then press  to confirm. Bluetooth is active when the little box alongside the writing is filled with a cross, vice versa the box will be empty.