

use & maintenance
MANUAL



CE

DECLARATION OF CONFORMITY

The following declaration is attached to the compressor in original copy.

All identification data: manufacturer, model, code and serial number are stamped on EC label.

For any request for copies it is ESSENTIAL to provide ALL the data stamped on EC label.

I - Dichiaro sotto la sua esclusiva responsabilità, che il compressore d'aria qui di seguito descritto è conforme alle prescrizioni di sicurezza delle direttive: 2006/42/CE, 2006/95/CE, 2004/108/CE, 2009/105/CE.	TP - Δηλώνει, με αποκλειστικά δική της ευθύνη, ότι ο συμπιεστής αέρος που περιγράφεται παρακάτω ανταποκρίνεται στις προδιαγραφές ασφαλείας των οδηγιών 2006/42/ΕΕ, 2006/95/ΕΕ, 2004/108/ΕΕ, 2009/105/ΕΕ
GB - Declares under its sole responsibility that the air compressor described below complies with the safety requirements of directives: 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC	PL - oświadcza pod pełną własną odpowiedzialność, że opisana niżej sprężarka powietrzna odpowiada wymaganiom bezpieczeństwa zawartym w Dyrektywach 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC
F - Déclare sous son entière responsabilité que le compresseur d'air décrit ci-après est conforme aux prescriptions de sécurité des directives : 2006/42/CE, 2006/95/CE, 2004/108/CE, 2009/105/CE	CZ - prohlašuje s plnou odpovědností, že uvedený vzduchový kompresor vyhovuje bezpečnostním požadavkům směrnic: 2006/42/ES, 2006/95/ES, 2004/108/ES, 2009/105/ES
D - Erklärt unter ihrer alleinigen Verantwortung, daß der in Folge beschriebene Luftkompressor den Sicherheitsvorschriften der Richtlinien: 2006/42/EG, 2006/95/EG, 2004/108/EG, 2009/105/EG	SK - Zodpovedne vyhlasuje, že uvedený vzduchový kompresor zodpovedá bezpečnostným požiadavkám smerníc 2006/42/ES, 2006/95/ES, 2004/108/ES, 2009/105/ES
E - Declara bajo su exclusiva responsabilidad que el compresor de aire descrito a continuación responde a las prescripciones de seguridad de las directivas :2006/42/CE, 2006/95/CE, 2004/108/CE, 2009/105/CE	H - teljes felelősségének tudatában tanúsítja, hogy az alábbiakban jellemzett légkompresszor a 2006/42/EC(from 29/12/2009), 2006/95/EC, 2004/108/EC, 2009/105/ECE
NL - Verklaart onder zijn eigen verantwoordelijkheid dat de hieronder beschreven uchtcompressor in overeenstemming is met de veiligheidsvoorschriften van de richtlijnen: 2006/42/EG, 2006/95/EG, 2004/108/EG, 2009/105/EG	LT - Su visa atsakomybe pareiškia, kad žemiau aprašytas oro kompresorius atitinka saugumo direktyvų 2006/42/ES, 2006/95/ES, 2004/108/ES, 2009/105/ES
N - Erklærer under eget ansvar at luftkompressoren her beskrevet er i overensstemmelse med sikkerhedsforskrifterne i direktivene: 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC	LV - Apliecinā zem savas pilnīgas atbildības, ka apakšā aprakstītais gaisa kompresors atbilst direktīvu: 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC
S - Försäkrar under eget ansvar att den luftkompressor som beskrivs följande är i överensstämmelse med säkerhetsföreskrifterna i EU-direktiv: 2006/42/EG, 2006/95/EG, 2004/108/EG, 2009/105/EG	EST - Avaldab enda täieliku vastutusega, et edaspidi kirjeldatud õhukompressor vastav ohutuse nõudmistele direktiividele 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC
DK - Forsikrer på eget ansvar, at luftkompressoren, der beskrives nedenfor, er i overensstemmelse med sikkerhedsforskrifterne i direktiverne: 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC	SLO - Na lastno odgovornost izjavlja, da je spodaj opisani zračni kompresor v skladu z varnostnimi predpisi, ki veljajo za stroje 2006/42/EU, 2006/95/EU, 2004/108/EU, 2009/105/EU
P - Declara sob a sua exclusiva responsabilidade que o compressor de ar descrito a seguir está em conformidade com as prescrições de segurança das directivas:2006/42/CE, 2006/95/CE, 2004/108/CE, 2009/105/CE	RO – Declara pe propria raspundere ca,compresorul de aer denumit in continuare,este in conformitate cu cerintele de securitate cuprinse in directivele: 2006/42/CE, 2006/95/CE, 2004/108/CE, 2009/105/CE
FI - vakuuttaa, että seuraavassa esitelly ilmakompressorin vastaa alla lueteltujen direktiivien turvallisuusvaatimuksia: 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC	RU - Заявляет под свою полную ответственность, что нижеописанный воздушный компрессор соответствует требованиям безопасности согласно директивам, 2006/42/EC, 2006/95/EC, 2004/108/EC, 2009/105/EC

INDEX

<i>GENERAL INFORMATION</i>	<i>3</i>
<i>SAFETY INDICATIONS</i>	<i>4</i>
<i>INSTALLATION.....</i>	<i>6</i>
<i>TECHNICAL FEATURES.....</i>	<i>7</i>
<i>CONTROLS AND SETTINGS</i>	<i>8</i>
<i>ALARMS</i>	<i>10</i>
<i>OPERATION.....</i>	<i>11</i>
<i>MAINTENANCE</i>	<i>12</i>
<i>TROUBLE SHOOTING.....</i>	<i>14</i>
<i>WIRING DIAGRAM</i>	<i>15</i>

OUTFIT

The following accessories are supplied with the compressor:

- user's guide
- anti-vibration elements
- oil/condensate exhaust tube

Check that the above accessories are available. Once the goods have been delivered and accepted, no complaints are accepted.

CONDITION OF THE MACHINE WHEN SUPPLIED

Every compressor is shop tested and delivered ready to be installed and to be set at work.

Oil used is: ROTENERGY PLUS.

GENERAL

- Rotary compressors are intended for heavy continuous industrial use. They are especially suitable for industrial applications requiring high air consumption for a long time.
- The compressor should be run and operated only in compliance with the indications given in this manual. Safely keep this manual in a known and easily reachable place for the whole working life of the compressor.
- A supervisor shall be appointed in the company, in which the compressor is installed. He/she shall be responsible for compressor inspections, adjustments and maintenance. Should a substitute be appointed for the supervisor, he/she shall carefully read the user's guide and all possible comment on service and maintenance carried out so far.

SYMBOLS USED IN THE MANUAL

Some symbols are used to highlight danger situations, give recommendations or information. These symbols are usually positioned next to the text, a figure or at the top of a page (in this case they refer to all subjects dealt with in that page).

Carefully read symbol meaning below.

**CAUTION!**

Important description on service, dangerous situation, safety, accident prevention recommendations and/or very important information.

**POWER OFF!**

All operations to be strictly carried out only after powering off the machine.

**STOP MACHINE!**

All operations to be strictly carried out only after stopping the machine.

**SPECIALIZED PERSONNEL!**

All operations to be strictly carried out only by specialized technician.

SYMBOLS ON THE COMPRESSOR

The compressor has several labels to highlight possible danger and give recommendations on what to do during machine operation or in special situations.

Please comply with these indications.



Danger! Hot!



Danger! Electric shock!



Danger! Hot gas or harmful gas within working area



Danger! Pressurized container



Danger! Mechanical moving parts



Caution! Maintenance works in progress



Machine with automatic start-up



Prohibited! Do not open doors during compressor operation



Prohibited! Press emergency button for compressor immediate stop. Do not use line knife switch.



Prohibited! Do not use water on electric equipment to extinguish fire.



Compulsory! Read instructions for use carefully.

WHAT TO DO:

Make sure that mains voltage corresponds to the voltage indicated on CE plate and that cable of suitable cross-section are used for electric connections.

Always check oil level before starting the compressor.

Be familiar with emergency stop control and all other controls.

Unplug the connector before any maintenance work, so to avoid accidental start.

Ensure that all parts have been correctly reassembled after any maintenance work.

Keep children and animals off the working area to avoid injuries caused by devices connected to the compressor.

Ensure that temperature of the working environment ranges between +5 and + 45°C.

The compressor should be installed and operated in a non-explosive environment.

Leave at least 80 cm between the compressor and the wall. This prevents obstructing the air passage of the electric fan.

Press the emergency button on the control panel only in case of actual need so as to avoid possible damages to people or the very compressor.

When calling for technical assistance and/or advice, always mention model and serial number indicated on CE plate.

Always follow the maintenance schedule specified in the user's guide.

WHAT NOT TO DO:

Do not touch inner parts and pipes as they are very hot during compressor operation and stay hot for a certain time after compressor stops.

Do not position inflammable or nylon objects or cloths close to and onto the compressor.

Do not move the compressor when the tank is under pressure.

Do not operate the compressor if the power cable is damaged or defective or if connection is unstable.

Do not operate the compressor in wet or dusty environments.

Never aim the air jet at people or animals.

Do not allow unauthorized people to operate the compressor and give them all required instructions.

Do not hit fans with blunt objects as they might break during compressor operation.

Never operate the compressor without air filter.

Do not tamper with safety and adjusting devices.

Never operate the compressor when doors/panels are open or removed.


PRODUCT IDENTIFICATION

The compressor You have purchased has its own CE plate showing the following data:

- 1) Manufacturer's data
- 2) CE mark – year of manufacture
- 3) TYPE = name of the compressor
CODE = compressor code
SERIAL NO. = serial number of the compressor You have purchased (to be always mentioned when calling for technical assistance)
- 4) max. operating pressure (bar and PSI) – compressor noise level in dB(A)
- 5) electric data: voltage (V/ph), frequency (Hz), absorption (A) - power (HP and kW), rotations per minute (Rpm).
- 6) other approvals

1	<div style="display: inline-block; font-size: 2em; font-weight: bold;">C</div> <div style="display: inline-block; font-size: 2em; font-weight: bold;">E</div> <div style="display: inline-block; border: 1px solid black; padding: 2px 5px; margin-left: 5px;">2</div>
3	
	4
5	6

MACHINE DESCRIPTION



UNPACKING AND HANDLING THE MACHINE

When delivered, compressor top is protected by cardboard packing.

Wear suitable protective gloves and then cut outer straps and then remove cardboard from the top. Check the (outer) good condition of the machine before moving the compressor. Visually check that no parts are damaged. Also ensure that all accessories are available.

Lift the machine using a fork lift truck. Fit the anti-vibration elements into their proper seat and move the machine to the room chosen for its location with maximum care.

Keep all packing materials at least for the warranty period for possible moving. In case of need, it will be safer for delivery to the technical assistance dept.

Then, dispose of packing materials in compliance with current laws.


LOCATION (fig. 2)

The room chosen for the installation of the compressor should meet the following requirements and comply with what is specified in the current safety and accident prevention regulations:

- **low percentage** of fine dust,
- **proper room ventilation and size** that allow room temperature under 45°C. In the event of inadequate hot air discharge, fit the exhaust fans as high as possible.

Condensate should be collected either into a pit or a tank.

The dimensions of the spaces are indicative only but it is advisable to follow them as closely as possible.




INSTALLATION

GB

ELECTRICAL HOOK-UP (fig. 3)

- The mains cable should have a cross-section suitable for the machine power and should include no. 3 phase wires, no. 1 neutral cable and no. 1 earth wire.
- Between the mains cable and the compressor control panel a fused switch near the point where the cables go into the machine **is absolutely necessary**. The switch should be at least at 1.7 m from the ground.
- The switch (A) should be easily reached by the operator. The cables should be of the approved type and installed with the following grade of protection: minimum IP44.

N.B. To determine the cables cross-section and the type of switch refer to the data reported on the technical table. Sizing according to "VDE 0100, Part 430 and 523", star-delta starter, 30° C ambient temperature and cable length lower than 50 meters.



Electric connection		SE 3 (M)	SE 3	SE 4	SE 5	5 TA	7 TA
conductor min. section	mm ²	3G2,5	4G1,5	4G2,5	4G2,5	4G2,5	4G2,5
magnetic thermal switch	A	20	10	10	16	16	20
fuses	AgI	20	10	16	20	16	16

TECHNICAL FEATURES

TECHNICAL CHARACTERISTICS		Hp	3 M		3		4		5,5		5,5 TA			7,5 TA														
Work pressure	bar g		8	10	8	10	8	10	8	10	8	10	13	8	10	13												
Pump group	type		FS 14																									
Air outflow rate (according to ISO 1217 annex C)	l/m in		300	260	325	290	430	385	580	485	580	485	350	720	650	485												
Oil quantity	l		2,2												2,3													
Quantity of top up oil	l		0,25																									
	°C		-		-		-		-		-			-														
Heat carried	kJ/h		7524		7524		10260		13680		13680			13680														
Fan flow rate	m 3/h		600																									
Oil residuals in the air	m g/m 3		2 - 4																									
Electric motor	type		B3B14																									
Nominal Input	kW		2,2		2,2		3		4		4			5,5														
Max input power from the mains	kW		3,21		3		3		3,8		4,2		4,8		4,8		5,2		5,1		5		6,55		6,70		6,85	
Electric box protection class	IP														54													
Ambient temperature limit	°C		2 - 45																									
Sound pressure (according to Pneurop/Cagi PN2CPTC2)	dB(A)		58				59				60				60				65									
ELECTRICAL DATA																												
Voltage power supply	V/Ph		230/1		400/3																							
Auxiliary voltage	V/Ph		-		-		-		-		24/1			24/1														
Current input at start up	A		75		35		40		52		24			30														
Max current input	A		14,3		5,2		5,2		6,2		6,6		8,7		8,4		8,7		8,5		8,4		10,2		10,5		10,2	
Max. Absorbed current (vacuum)	kW		-		-		-		-		1,21			1,52														
Electric motor protection degree			55/F																									
Service factor			1,1																									
PROTECTION DEVICES																												
Oil circuit max temperature	°C		110																									
Thermal motor relay calibration	A		14,5		5,5		6,6		8,8		5,2			6,8														
Safety valve calibration	bar		14																									
DIMENSIONS AND WEIGHT																												
Length	m m		580																									
Width	m m		480																									
Height	m m		760																									
Weight	kg		87		87		92		93		94			97														
Air outlet	G"		1/2"																									
DIMENSIONS AND WEIGHT + TANK + DRYER		l	200																									
Length	m m		1440																									
Width	m m		510																									
Height	m m		1280																									
Weight + serbatoio	kg		144		144		149		151		152			155														
Weight + tank + dryer	kg		175		175		180		182		182			185														
Air outlet	G"		1/2"																									



CONTROL PANEL

SE VERSION - fig.4

1. Air pressure gauge:
outlet air pressure reading
2. ON/OFF switch:
starting and stopping the compressor
3. Service hour counter:
operation hours reading

TA VERSION - fig.5

The TA version is equipped with an electronic control called "Easytronic II Micro" which manages all of the compressor functions

1. START key:
controls start up of the compressor.
2. RESET key:
controls turning off of the compressor.
3. "Function" key:
allows movement from one display to the other.
4. Display:
shows the information.
5. Alarm warning lights:
turn on in case of alarm.
6. Screw warning light:
turning on means that the compressor is loading.
7. Stand-by warning light:
turning on indicates the compressor is waiting.
8. Emergency shutdown button:
pressing this button causes immediate stoppage of the compressor. **To be used only and exclusively** in the event of real need.

WORKING TIMES

SE VERSION



- START-STOP function: the compressor starts from the pressure switch command. When maximum pressure is reached it stops and restarts automatically only if the minimum pressure value allowed is reached.

TA VERSION

- The compressor function is regulated by the electronic control unit, which measures the pressure by means of a pressure transducer and determines the stopping of the machine when the maximum pressure is reached (vacuum pressure) and it restarts when the pressure decreases to the minimum calibration level (load pressure)
 - The machine stop is a delayed type that does not occur at exactly the same time as reaching maximum P value but after a certain time (vacuum time), during which no air is taken.
 - The factory vacuum time is 75 seconds but check that the n° of switch on per hour DO NOT exceed the max advised n° of 10. If above 10, increase the "vacuum time", in order to avoid not necessary switch on and switch off cycles.

PRESSURE REGULATOR

The User should install an intercepting and regulating device downstream of the compressor in order to set the air distribution line according to his/her needs.



MODIFIABLE PARAMETERS

These settings apply exclusively to the models fitted with Easytronic II Micro power unit.

User menu

With the compressor off, keep the "Function" key pressed for at least 5 seconds.

N°	Parameter	U.M	Min. value	Default value	Max value
U0	Set loadless pressure (*)	Bar	0.5	10.0	15.0
U1	Set loading pressure (**)	Bar	0	8.5	(Set P loadless) – 0.5
U2	Unit of measure (***)	Bar/Psi	0	1	1

- to select the parameter desired use START (forward) and RESET (back) keys,
- then press the FUNCTION key to show the value of the chosen parameter,
- to change the value use START (to increase) and RESET keys (to decrease),
- confirm the value set by pressing the FUNCTION key.
- The power unit returns to the main menu, and after 5 seconds without pressing any key it returns to the standard display.

(*) Set loadless pressure: indicates the value of pressure at which the compressor starts the loadless operating cycle.

(**) Set loading pressure: indicates the value of pressure at which the compressor starts compressing air again.

(***) 1=bar, 0=psi

Assistance menu

The settings below must be performed only by authorised technicians.

With the compressor off or in alarm status, keep the "FUNCTION" and "RESET" buttons pressed for at least 5 seconds, then a password will be requested.

N°	Parameter	U.M	Min. value	Default value	Max value
A0	Temperature to power fan	°C	0	80	150
A1	Time loadless	sec.	30	75	900
A2	Delay time in stoppage phase	sec	30	60	900
A3	Enable pressure sensor (*)		0	1	1
A4	Enable temperature sensor (*)		0	1	1
A5	Enable automatic start (*)		0	0	1
A6	Enable phase sequence (*)		0	1	1
A7	Expiry oil hours	hours	0	4000	65536
A8	Expiry oil filter hours	hours	0	4000	65536
A9	Expiry air filter hours	hours	0	2000	65536
A10	Expiry oil separator hours	hours	0	4000	65536
A11	Total hours (**)	hours	0	—	65536
A12	Loading hours (**)	hours	0	--	65536

(*) 1=enabled, 0=disabled

- to select the parameter desired use START(forward) and RESET keys (back),
- then press the FUNCTION key to show the value of the chosen parameter,
- to change the value use START (to increase) and RESET keys (to decrease),
- confirm the value set by pressing the FUNCTION key.
- The power unit returns to the main menu, and after 5 seconds without pressing any key it returns to the standard display.

During normal operation of the compressor the following signals can occur:

Alarm warning lights (rif.5, fig.5)



Water present in the separator tank. (Optional, not available in the standard configuration)

Blinking warning light = signal without compressor block

Fixed warning light = compressor block

Drain the condensate from the oil separator tanks (see chapter "Maintenance").



The warning light turns on to indicate a wrong electrical connection. The compressor blocks.

Check connection to the mains cable and to the terminals of the electrical panel of the compressor.



Oil temperature.

Blinking warning light = pre-alarm without compressor block

Fixed warning light = alarm with compressor block

Let the compressor cool down and check the oil level.



The maximum temperature of the motor has been exceeded. The compressor blocks.

Let the motor cool down and check setting of thermal relay.



Indicates there has been a blackout. The compressor blocks.

With compressor stopped, press RESET to disable the alarm before restarting.

Alarm messages, the following alarms are shown on screen:

- | | |
|-----|--|
| AL1 | Faulty or broken temperature sensor with blockage of compressor.
Replace sensor. |
| AL2 | Faulty or broken pressure sensor with blockage of compressor.
Replace sensor. |
| AL3 | No phase or phase sequence transformer not operational with blockage of compressor.
Check presence of phase and if necessary replace transformer. |
| AL4 | Maximum alarm pressure with blockage of compressor.
Contact an assistance centre to remove the cause of the problem. |
| AL5 | Fast rise in temperature with blockage of compressor.
Contact an assistance centre to remove the cause of the problem. |
| AL6 | The emergency button has been pressed.
Reset the button to correct position. |

All alarms cause the compressor to block, which can be restarted only when the problem which has caused the blockage is resolved.

The alarm signal remains even after the problem has been solved, to disable it press the RESET button before restarting the compressor.

Maintenance signalling

The power unit also signals periodic maintenance operations, the internal counters decrease at each hour of loading of the compressor until zero is reached, at this point the maintenance signal will appear on the display:

- | | |
|-----|--|
| CH1 | Expiry of oil hours.
Replace oil. |
| CH2 | Expiry of oil filter hours.
Replace oil filter |
| CH3 | Expiry air filter hours
Replace air filter. |
| CH4 | Expiry of oil separator hours
Replace oil separator filter. |

If more signals are verified at the same time they are displayed in sequence.

Once the maintenance has been performed the internal counters must be reprogrammed.

Before starting the machine for the first time, **check that:**

- the mains voltage is the same as the voltage on the CE plate;
- the electric connections have been made using cables of proper cross-section,
- the (wall) main power switch has suitable fuses;
- the oil level is over the minimum level - top up with the same type of oil if necessary;

CONNECT THE TANK WITH A HOSE.

Only specialised technicians can start the compressor for the first time.

SE VERSION (fig.4):


Before starting up the machine remove the rear panel, switch on the machine by positioning switch (2) in the ON position and check the correct rotating direction of the motor, as indicated by the arrows applied on the screw-motor plate (fig.6). If the rotating direction is not correct, immediately switch off the machine taking both the switch (2) and the wall switch to the OFF position.

Open the electric compartment and invert the position of the electric cables of the two phases in the powering terminal board.

Close the electric compartment and restart.

TA VERSION (fig.5): Premendo il tasto START (1) si avvia la **procedura di accensione**.

The **turning on procedure** starts by pressing the START key (1).

The Stand-by led (7) blinks and after a few seconds the presence of the phases and their correct sequence is checked, if the compressor blocks and the warning light  turns on the phase sequence device has intervened, press the RESET key (2) and bring the wall switch to OFF position.

Open the electric compartment and invert the position of two phases in the power terminal box. Close the electrical compartment and restart.

The start up procedure is repeated: the Screw led (6) blinks and after a few seconds it becomes fixed, the load phase starts until the "set loadless pressure" value is reached.




The Screw led (6) blinks again and the loadless operation phase begins.

If at the end of the loadless operation (default 75 sec.) the pressure has not fallen below the "set load pressure" value the compressor stops and the Stand-by led turns on (7); otherwise upon reaching the "set load pressure" value the compressor restarts the loading phase and the Screw led turns on in fixed mode (6).

During normal function, press the Function key (3). The following information will be displayed:

- pressure,
- temperature,
- total hours of operation (with compressor on),
- hours of operation loaded (with compressor in load phase).

By pressing the RESET key (2) the **turn off procedure** starts, the Screw led (6) blinks and the compressor enters the loadless operation mode for the time set by the parameter "delayed stop time" (default 60 sec.). At the end of the cycle the compressor stops.





MAINTENANCE

- Correct maintenance is crucial to achieve maximum efficiency of your compressor, and to lengthen its operating life.
- It is also important to comply with the maintenance intervals recommended, but it must be remembered that such intervals are suggested by the manufacturer in the event that the environmental conditions of use of the compressor are optimal (see "Installation" chapter).
- The maintenance intervals can therefore be reduced depending on the environmental conditions in which the compressor operates.
- The oil used is RotEnergy Plus, the use of a different oil does not guarantee perfect efficiency and compliance with the maintenance intervals.
- The following pages describe the routine maintenance operations which can be performed by the person in charge of the compressor, the non-routine maintenance operations must instead be performed by an authorised technical assistance centre.

Maintenance table

TYPE OF MAINTENANCE	MAINTENANCE SCHEDULE	
	work hours	o at least
ORDINARY MAINTENANCE		
Condensation release	-	twice per month
Oil level check and refill	500	once per month
Clean filtering element	500	-
Check the transmission belt	500	-
Check blockage and clean radiator	1000	once a year
Replace the filtering element	2000	once a year
Oil filter substitution	4000*	once a year
Discharge oil filter substitution	4000*	once a year
Total oil change	4000*	once a year
One-way draining valve substitution	4000*	once a year
EXTRAORDINARY MAINTENANCE		
Substitute the transmission belt	6000	
Suction valve overhaul	8000	
Minimum pressure valve overhaul	8000	
Solenoid-valve substitution	12000	
Substitute the flexible tube	12000	
Substitute the electric motor bearings	12000	
Screw compressor overhaul	20000	
* When using mineral oils, intervals are reduced to 1500 hours or one year		

If the hourly limit is not reached, the maintenance operations highlighted in **bold** must be performed at least **1 time a year**.

- To verify correct machine operation, perform the following checks **after the first 100 hours of work**:

- 1) **Check the oil level**: top up with the same type of oil if necessary.
- 2) **Check for proper screw tightening**: in particular the power electric connection screws.
- 3) Visually check that all **fittings seal properly**.
- 4) Check the **belt tension** and if necessary, reset it.
- 5) Check the **hours of work** and the **type of service selected**
- 6) Check **room temperature**.

BEFORE MAINTAINING THE MACHINE ALWAYS PERFORM THE FOLLOWING:

- ✓ **Press the machine automatic stop button** (do not use the emergency button).
- ✓ Power the machine off by means of the wall outer switch.
- ✓ Close the line cock.
- ✓ Make sure that no compressed air is inside the oil separator tank.
- ✓ Remove fairing and/ or panels.

DRAIN CONDENSATE

The oil/air mixture cooling is set at a higher temperature with respect to the dew point of the air (under standard operating conditions of the compressor). However, the condensate in the oil cannot be fully removed.

Blow off compressed air through cock **B** and then close it as soon as oil begins to flow out instead of water. Check the oil level and top up if necessary

CONDENSATE IS A POLLUTING MIXTURE! It must not be let into the sewage.

OIL CHECK AND TOP UP IF NECESSARY

(Fig.7)

With the **compressor off**, check the oil level by means of the warning indicator positioned on the front panel 2.

If the level is under the minimum, remove the front panel and refill through hole **A**. Quantity of oil for refilling from the min to the max level = 0.25 litres.

Use **ONLY** oil of the same type (RotEnergy Plus).

CLEANING/REPLACING THE FILTERING ELEMENT (Fig.8)

With the compressor stopped, remove the lid and carefully clean the filtering element **D** using compressed air from the inside towards the outside. Check, against the light, for the presence of possible tears and if necessary, replace it.

The filtering element and the lid should be mounted with care, so that no dust can enter the compression unit.

Never allow the compressor to function without the filtering element.

Replace the filtering element D. Alarm signal CH3

CLEANING THE RADIATOR

It is recommended that in case of over temperature anomalies and however, at least once a year that the radiator is cleaned.

Proceed as follows:

position a sheet of protective plastic under the radiant pack;
spray (with a washing + detergent gun) from inside towards the outside.

- check that the air flows correctly by means of the radiator.

REPLACING THE OIL FILTER (Fig.9)

With the compressor stopped, remove the lid and the front panel.

Alarm signal CH2

At each change replace also the oil filter **E**, unscrew the old filter and replace it. Always apply some oil on the edge of the filter and on the seal before refitting manually the filter.

REPLACING THE SEPARATOR FILTER (Fig.9)

With the compressor stopped, remove the lid and the front panel.

ALARM SIGNAL CH4

The oil separator filter **D** cannot be cleaned, but must be replaced.




- Unscrew filter manually (or if necessary use an appropriate filter tool) turning it anticlockwise.
- After having slightly greased the oil separator filter seal and O-ring, fit the new filter by turning clockwise.

REPLACING THE OIL (Fig.7)

When the compressor is hot - above 70 °C, replace the oil.

Alarm signal CH1

- Remove the front panel
- Connect the drain hose provided to cock **B** located at the base of the separator tank.
- Unscrew the plug from hole **A**, open the cock and allow the oil to drain in to a container until draining is complete.





- Close cock B and withdraw the hose.
- Refill with new oil using hole A (quantity for complete refilling: 2.2 litres) and refit the plug.
- Start up the compressor and allow to function for 5 minutes, and then shut it down. Discharge all of the air and wait 5 minutes before controlling the oil level. Top up, if necessary.

THE EXHAUSTED OIL IS HIGHLY POLLUTANT! For its disposal comply with the current laws on environmental protection.

- The first equipment oil is: RotEnergy Plus.

In the case of changing the type of oil, operate only for the complete replacement. NEVER MIX DIFFERENT TYPES OF OIL.

In this case, change also the oil filter and the separator filter.

CHECKING THE TRANSMISSION BELT TENSION (Fig.10)

When the compressor is stopped, remove the rear panel and check the belt tension.

Use a suitable measuring instrument that determines with precision the belt tension degree by means of a frequency measuring device in order to perform this control.

Operate as follows:

- Place the microphone of the measuring instrument near to the belt (about half way) and hit the belt with a wrench.
- Read the value detected by the instrument and if different from the values indicated in the table (fig.10A), adjust the tension:


Value higher = belt too tight

Value lower = belt too loose

Adjust by loosening the four bolts and adjust the tension with screw C2.

After adjusting, tighten the bolts C1.

Check the frequency value again and if necessary, repeat the operation.



REPLACING THE TRANSMISSION BELT (Fig.10)

When the compressor is stopped, remove the rear panel. Loosen the four bolts C1 and act on screw C2 loosening belt C until completely loose.

Remove the belt and replace it with a new one.

After replacing, check the belt tension as described previously.


REPLACING THE MINIMUM VALVE (Fig.11)

Replace the seals highlighted with the letter F.

REPLACING THE FLEXIBLE HOSES

It is recommended that they are replaced when changing the oil.

Loosen the hose fittings, replace them and tighten with force the fittings. Continue with the final phases of the oil changing procedure.




TROUBLESHOOTING

GB




Problem	Cause	Remedy
Motor stopped (thermal relay operation signal)	Voltage too low	Check voltage, press Reset and then restart.
	Overtemperature	Check motor absorption and relay setting. In case of regular absorption press Reset and restart.
	Fan motor overtemperature	Check fan motor and clixon condition
Oil consumption high	Drainage faulty	Check oil drain hose and check valve
	Oil level too high	Check oil level and drain some, if necessary
	Oil separator filter broken	Replace oil separator filter
	Oil separator filter seal leaking	Replace oil separator nipple seals
Intake filter leaks oil	Intake regulator stays open	Check regulator and solenoid valve
Safety valve opening	Pressure too high	Check the pressure settings.
	Intake regulator does not close at the end of the cycle	Check regulator and solenoid valve
	Oil separator filter clogged	Replace oil separator filter
Sensor for compressor temperature triggered	Room temperature too high	Improve ventilation
	Radiator clogged	Clean radiator with solvent
	Oil level too low	Top up oil
	Cooling fan does not start	Check the electric fan motor.
Compressor performance low	Air filter dirty or clogged	Clean or replace filter
Compressor does not compress air while running	Regulator closed. It cannot open because dirty.	Remove intake filter and check for proper manual opening. Remove and clean, if necessary.
	Regulator closed. It cannot open because no command is received.	Check for signal on solenoid valve. Replace damaged part, if any.
Compressor compresses air over max. pressure value	Regulator open. It cannot open because dirty.	Remove and clean regulator
	Regulator open. It cannot open because no command is received.	Check for signal availability between pressure switch and solenoid valve. Replace damaged part, if any.
Compressor does not start	Oil separator filter clogged	Replace oil separator filter
	Min. pressure valve does not close perfectly	Remove the valve, clean and replace seal, if necessary
Compressor hardly starts	Voltage too low	Check mains voltage
	Tube leaking	Tighten fittings

WIRING DIAGRAM HP3-4-5 T.P 400 - 50/60



Rif./Ref.	Denominazione/Denomination	HP3	HP4	HP5
FU1-FU2	Fusibili/Fuses 1A 5x20			
SP	Telepressostato/Tele pressure switch	4-6,3	6,3-10	6,3-10
L	Bobina di minima/Minimum coil 400 V			
D	Controllo elettronico temp./Electronic temperature control			
ST	Sonda termica/Safety thermostat			
PT	Contaore/Hour counter 230 Vac			
Y V	Elettrovalvola/Electric valve NA 230 Vac			
X	Morsettiera/Terminal board			
	Sez. cavo motore/Motor cable cross-section (mmq)	4G1,5	4G1,5	4G2,5




N.B.

- 1) Sez. ausiliari = 1mmq
- 2) (*) = 400V AC3

Rif./Ref.	Denominazione/Denomination	HP5	
		230V	400V
TC1	Trasformatore/Transformer Pr.0/230/400 Sec.0/12/24		
TC2	Trasformatore/Transformer Pr.0/230/400 Sec.0/6		
SB	Pulsante di emergenza/Emergency Button + n.2 NC 230V 10°		
FU1	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 4A 500V		
FU2.FU3	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 1A 500V		
FU4.FU5	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 2A 500V		
FU6	Fusibile ceramico/Ceramic Fuse 10.3 x38 GF 500mA 500V		
KM1	Contattore linea-Line Contactor bob.24 V 50/60 Hz	5,5 KW(*)	3 KW(*)
KM2	Contattore triangolo-Triangle Contactor bob.24 V 50/60 Hz	5,5 KW(*)	3 KW(*)
KM3	Contattore stella-Star Contactor bob.24 V 50/60 Hz	4 KW(*)	3 KW(*)
KA	Rele' ausiliario-Auxiliary Relay 2 contatti bob. 24Vac		
FR	Rele' termico-Termal Relay reset MAN/AUT - 1L+1R	(7-10)	(4,5-6,3)
YV	Elettrovalvola-Solenoid Valve 24 VAC 50/60 Hz 8VA		
BP	Trasduttore di pressione-Pressure Transducer 0-16 Bar 4-20mA		
D	Controllore elettronico-Electronic controller 12VAC		
ST	Sonda termica-Temperature Probe per controllore		
MV	Motore E.V.raffreddamento-Motor cooling fan 230/1/50-60 Hz	70 W	70 W
	Sez. cavo motore-Section Cable Motor (mmq)	7G1,5	7G1,5

WIRING DIAGRAM TA 7



N.B.
1) Sez. ausiliari = 1mmq
2) (*) = 400V AC3

Rif./Ref.	Denominazione/Denomination	HP7	
		230V	400V
TC1	Trasformatore/Transformer Pr.0/230/400 Sec.0/12/24		
TC2	Trasformatore/Transformer Pr.0/230/400 Sec.0/6		
SB	Pulsante di emergenza/Emergency Button + n.2 NC 230V 10°		
FU1	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 4A 500V		
FU2.FU3	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 1A 500V		
FU4.FU5	Fusibili ceramici/Ceramic Fuse 10.3 x 38 GF 2A 500V		
FU6	Fusibile ceramico/Ceramic Fuse 10.3 x38 GF 500mA 500V		
KM1	Contattore linea-Line Contactor bob.24 V 50/60 Hz	7,5 KW(*)	4 KW(*)
KM2	Contattore triangolo-Triangle Contactor bob.24 V 50/60 Hz	7,5 KW(*)	4 KW(*)
KM3	Contattore stella-Star Contactor bob.24 V 50/60 Hz	5,5 KW(*)	4 KW(*)
KA	Rele' ausiliario-Auxiliary Relay 2 contatti bob. 24Vac		
FR	Rele' termico-Termal Relay reset MAN/AUT - 1L+1R	(9-12,5)	(5,5-8)
YV	Elettrovalvola-Solenoid Valve 24 VAC 50/60 Hz 8VA		
BP	Trasduttore di pressione-Pressure Transducer 0-16 Bar 4-20mA		
D	Controllore elettronico-Electronic controller 12VAC		
ST	Sonda termica-Temperature Probe per controllore		
MV	Motore E.V.raffreddamento-Motor cooling fan 230/1/50-60 Hz	70 W	70 W
	Sez. cavo motore-Section Cable Motor (mmq)	7G1,5	7G1,5

