



## Room thermostat with Auto Timer, Option External Input RDE100..

for heating systems

- Room temperature control
- 2-position control with On/Off output for heating
- Comfort, Economy, Auto timer and Protection mode
- Auto time switch
- Adjustable commissioning and control parameters
- Mains-powered AC 230 V (RDE100) or battery-powered DC 3 V (RDE100.1)
- Multifunction input (RDE100.1 only) for external floor sensor, keycard contact, etc.

### Use

The RDE100.. is used to control the room temperature in heating systems.

Typical applications:

- Apartments
- Commercial spaces
- Schools

For the control of the following pieces of equipment:

- Thermal valves or zone valves
- Gas or oil boilers
- Fans
- Pumps
- Floor Heating

## Functions


---

- Room temperature control via built-in sensor or external input
- Selection of operating mode with operating mode touchkey
- Setting auto time switch (individual day, 7 day or 5-2 day)
- Display of current room temperature or setpoint in °C or °F
- Touchkey lock (manually)
- Setpoint lock
- Periodic pump run
- Reloading factory settings for commissioning and control parameters
- One multifunctional input (RDE100.1 only) freely selectable for:
  - Floor Heating temperature limitation function
  - Operating mode switchover contact (keycard, window contact, etc.)

## Temperature control

---

The RDE100.. acquires the room temperature with its built-in sensor and maintains the setpoint by delivering control commands. The switching differential is 1 K.



## Floor heating limitation function (RDE100.1 only)

---

The factory setting for this function is Off (disabled) and must be set to "On" if floor heating is used.

The external floor temperature sensor is connected to input X1,  $\perp$  and acquires the floor temperature. If the floor temperature exceeds the parameterized temperature limit xx °C (P14 = 1, P15 = 1, P16 = xx °C), the heating valve is fully closed until the floor temperature returns to a level below the parameterized limit. Typical application is rooms (dry floor).

If the application does not require floor heating temperature limitation but instead uses the external sensor as a source for both room temperature display and control, the parameters will have to be set as follows: P14 = 1, P15 = 0. A typical application is the bathroom (wet floor) where a constant floor temperature is required.

It is not recommended to have **only** an internal built-in room sensor for floor heating since there is a potential risk of overheating.

## Operating mode switchover function

---


This function allows keycard application, please refer to the section "Operating notes, Economy mode".

### Periodic pump run function

Can only be used when circulating pump or valve is controlled!

This function protects the pump or valve against seizing during longer off periods.  
Periodic pump run is activated for 3 minutes every 24 hours at 12:00.

Parameter	Pump status
P12 = 0 (Default)	Pump run off
P12 = 1	Pump run on



### Type summary

Product No.	Stock No.	Features
RDE100	<b>S55770-T278</b>	Mains-powered AC 230 V
RDE100.1	<b>S55770-T279</b>	Battery-powered DC 3 V










### Ordering

- When ordering, please indicate product No. / stock No. and description.
- Example:

Product No.	Stock No.	Description
RDE100	<b>S55770-T278</b>	Room thermostat

Valve actuators/external sensor must be ordered separately.

## Equipment combinations

Description		Product No.	Data Sheet
Electromotoric actuator		<b>SFA21..</b>	4863
Electrothermal actuator (for radiator valves)		<b>STA23..</b>	4884
Electrothermal actuator (for small valves 2.5 mm)		<b>STP23..</b>	4884
Damper actuator		<b>GDB..</b>	4634
Damper actuator		<b>GSD..</b>	4603
Damper actuator		<b>GQD..</b>	4604
Rotary damper actuator		<b>GXD..</b>	4622
Cable temperature sensor		<b>QAH11.1</b>	1840
Room temperature sensor		<b>QAA32 ..</b>	1747


## Mechanical design

The room thermostat consists 2 parts:

- Plastic housing which accommodates the electronics, the operating elements and the room temperature sensor
- Mounting plate with screw terminals

The housing engages in the mounting plate and is secured with a screw.

## Operation and settings



1) Operating mode touchkey


2) Set

3) Ok

4) Touchkey for decreasing a value

5) Touchkey for increasing a value

## Display




#	Symbol	Description	#	Symbol	Description
1		Indicating that batteries need to be replaced (only with battery-powered version RDE100.1)	12		Display of time
2		Protection mode (protection mode symbol can be enabled via parameter settings)	13	am pm	Morning: 12-hour format Afternoon: 12-hour format
3		Auto timer mode	14		Confirmation
4		View and set auto time switch	15	°F	Room temperature in degrees Fahrenheit
5		Comfort mode	16		Touchkey lock activated
6		Economy mode	17	°C	Room temperature in degrees Celsius
7		Escape	18		Display of room temperature, setpoint, etc.
8		External input enabled (RDE100.1 only)	19		Heating On
9		Permanent setpoint setting	20		Weekday 1 = Monday 7 = Sunday
10		Day and time setting	21		Timer bar
11		Holiday mode setting	22		Current room temperature

## Mounting and installation notes

---

Do not mount the thermostat in niches or bookshelves, not behind curtains, not above or near heat sources, and not exposed to direct solar radiation. Mount about 1.5 m above the floor.



### Mounting



- Mount the thermostat in a clean and dry location without direct air flow from a heating/cooling equipment, and not exposed to drip or splash water

### Wiring

See Mounting Instructions M1429 enclosed with the thermostat.



- Ensure that wiring, fusing and earthing comply with local regulations



- Correctly size the cables to the thermostat and the valve actuators



- Use only valve actuators rated for AC 24...230 V



- The AC 230 V mains supply line must have a circuit breaker with a rated current of no more than 10 A




- Disconnect from power supply before removing the unit from its mounting plate



- External Inputs X1,  $\perp$  may carry mains potential. Sensor cables or window contact must carefully install before powering up the thermostat






## Commissioning notes

---


<b>Commissioning</b>	<p>After power is applied, the thermostat carries out a reset during which all LCD segments flash, indicating that the reset was made correctly. After the reset, the thermostat is ready for commissioning by qualified HVAC personnel.</p> <p>The control parameters of the thermostat can be set to ensure optimum performance of the entire system. Please refer to Operating Instructions CB1B1422, section "Do you want to change parameters?".</p>
<b>Sensor calibration</b>	<p>If the temperature on the display does not agree with the room temperature effectively measured, the temperature sensor can be recalibrated. For that purpose, adjust parameter P04.</p>
<b>Setpoint lock</b>	<p>We recommend reviewing the setpoint lock (for public areas) in parameters P06 and P08 and changing them as needed.</p>
<b>Touchpad scanning rate</b>	<p>Since the thermostat uses touch technology and to minimize battery power consumption, a parameter P21 (adjustable from 0.25 to 1.5 seconds) is implemented for the user to adjust. This function is only valid for the battery-powered version and the default value is 1 second.</p> <p>This means that when, for a certain time, the user does not touch the touchpad, the unit operates in power saving mode and the touchpad is running at a scanning rate of 1 second.</p> <p>(From the calculation – assuming 4 operations per day on the thermostat, the estimated 1-second scanning rate results in a battery life of 1 year. If the user increases the scanning rate, the batteries' life is extended.)</p>
<b>Change of batteries (only with battery-powered version RDE100.1)</b>	<p>If the battery symbol  appears, the batteries are almost exhausted and should be replaced. Use alkaline batteries type AAA.</p>

## Operating notes

---

	<p>The RDE100.. provides Comfort, Economy, Auto timer and Protection mode. The difference between Comfort and Economy mode is only the room temperature setpoint. The changeover between Comfort, Economy and Protection mode is made either automatically by the auto time switch or by pressing touchkey <b>mode</b>.</p>
<b>Comfort mode </b>	<p>When Comfort mode is activated, symbol  appears on the display. The setpoint (20 °C) can be readjusted by pressing touchkeys <b>+</b> and <b>–</b>.</p>
<b>Economy mode </b>	<p>When Economy mode is activated, symbol  appears on the display. The setpoint (16 °C) can be readjusted by pressing touchkeys <b>+</b> and <b>–</b>.</p> <p>In <b>RDE100.1</b>, a window contact feature is that a user can connect a window contact to the input X1, . Depending on whether the window contact is configured to Normally Open or Normally Close (Parameter P14 = 2, Parameter P17 = 0 or 1), a change in this status will automatically switch the thermostat from any modes to Economy mode. This feature is good for public area. The factory setting for this function is Off (disabled).</p>

## Protection mode

If the temperature falls below 5 °C, the unit automatically activates the heating output. The symbol  appears only, if the icon is enabled via parameter settings.


## Time switch

When Auto timer mode is enabled, the changeover between the operating modes (Comfort and Economy mode) will take place automatically. There are three options for time switch setting: individual day, 7 day or 5-2 day. You can select Comfort or Economy mode in every 15 minutes interval of the day. The 0:00 to 24:00 hour time bar will allow you to set the mode throughout the selected day(s).

Default value	Day/s	Comfort mode	Economy mode
	Mo (1) – Fr (5)	6:00 – 8:00 hr 17:00 – 22:00 hr	22:00 – 6:00 hr 8:00 – 17:00 hr
	Sa (6) – Su (7)	7:00 – 22:00 hr	22:00 – 7:00 hr

Please refer to Operating Instructions CB1B1422, section "Do you want to enter your own time switch?"

## Holiday mode

When holiday mode is activated, symbol  appears on the display. The setpoint (12 °C) and the number of days a user is away can be readjusted by pressing touchkeys + and –.

## Maintenance notes

The thermostats are maintenance-free.

## Disposal



The devices are considered electronics devices for disposal in term of European Directive 2012/19/EU and may not be disposed of as domestic waste.

- Dispose of the device via the channels provided for this purpose.
- Comply with all local and currently applicable laws and regulations.
- Dispose of empty batteries at designated collection points.

## Technical data



### Power supply

#### Operating voltage

- RDE100 at L - N AC 230 V +10/-15%
- Frequency 50 Hz
- Power consumption 4 VA


- RDE100.1 DC 3 V (2 x 1.5 V alkaline batteries AAA)

For battery life (RDE100.1), see below (alkaline batteries type AAA).

Battery life calculation is based on the touchpad scanning rate during idle time (assuming a user presses 4 touchkeys per day):

Scanning rate 0.25 s	194 days battery life
Scanning rate 0.50 s	274 days battery life
Scanning rate 1.00 s	346 days battery life
Scanning rate 1.50 s	379 days battery life



Control inputs	Control input Q11-Nx (Com)			
	• Rating RDE100	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
	• Rating RDE100.1	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
External sensor (RDE100.1 only)	External sensor			
	‘X1’ - ‘⊥’ (Reference)	NTC3K/QAH11.1/QAA32		
	Or			
	Digital On/Off			
	‘X1’ - ‘⊥’ (Reference)	On/Off switch		
Control outputs	Control output Q12-Nx (NC contact)			
	Rating RDE100	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
	Rating RDE100.1	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
	Control output Q14-Nx (NO contact)			
	Rating RDE100	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
	Rating RDE100.1	(AC 24...230 V)	Max. 5(2) A	Min. 8 mA
Function data	External protection for incoming cable			
	Circuit breaker	Max. 10 A		
	Circuit breaker tripping characteristic	Type B, C or D to EN 60898 and EN 60947		
	Switching differential SD	1 K		
	Comfort mode	20 °C (5...35 °C)		
	Economy mode	16 °C (5...35 °C)		
	Holiday mode	12 °C (5...35 °C) (Standalone)		
	Built-in room temperature sensor			
	Setpoint setting range	5...35 °C (Comfort/Economy mode)		
	Accuracy at 25 °C	< ±0.5 K		
	Temperature calibration range	±3.0 K		
	Resolution of settings and displays			
	Setpoints	0.5 °C		
	Temperature value displays	0.5 °C		
	Environmental conditions	Operation		
As per IEC 60721-3-3				
Climatic conditions				
Class 3K5				
Temperature				
0...50 °C				
Humidity				
<95% r.h.				
Transport				
As per IEC 60721-3-2				
Climatic conditions				
Class 2K3				
Temperature				
-25...60 °C				
Humidity				
<95% r.h.				
Mechanical conditions				
Class 2M2				
Storage				
As per IEC 60721-3-1				
Climatic conditions				
Class 1K3				
Temperature				
-25...60 °C				
Humidity				
<95% r.h.				
Norms and standards	EU Conformity (CE)			
	CE1T1420xx <sup>*)</sup>			
	 C-Tick conformity to			
	EMC emission standard			
	AS/NZS 4251.1:1999			
	Safety class			
	II as per EN 60730-1, EN 60730-2-9			
	Pollution class			
	II as per EN 60730-1			
	Degree of protection of housing			
IP30 as per EN 60529				

Environmental  
compatibility


The product environmental declaration CE1E1420xx contains data on environmentally compatible product design and assessments (RoHS compliance, materials composition, packaging, environmental benefit, disposal).

General

Connection terminals for	Solid wires or prepared stranded wires 2 x 1.5 mm <sup>2</sup> or 1 x 2.5 mm <sup>2</sup> (Min. 0.5 mm <sup>2</sup> )
Weight	0.166 kg
Color of housing front	RAL9003


\*) The documents can be downloaded from <http://siemens.com/bt/download>.

## Connection diagrams



### RDE100


N1	Room thermostat
Y1	Valve actuator
L	Live, AC 230 V
N	Neutral conductor, AC 230 V




### RDE100.1

Lx	Live, AC 24 ... 230 V
Q11, Q12	NC contact (for NO valves)
Q11, Q14	NO contact (for NC valves)
Nx	Neutral conductor, AC 24...230 V
X1	External input signal
	Measuring neutral for external input
B1	Temperature sensor (Floor temperature limit)
S1	Switch (keycard, window contact)


## Appication examples




Room thermostat with direct control of a gas-fired wall-hung boiler



Room thermostat with direct control of a gas-fired floor-standing boiler



Room thermostat with direct control of a heating circuit pump (precontrol by manual mixing valve)



Room thermostat with direct control of hydronic floor heating system

F1 Thermal reset limit thermostat  
F2 Safety limit thermostat  
M1 Circulating pump

N1 RDE100.. room thermostat  
Y1 Mixing 3-port valve with manual adjustment  
Y2 Magnetic valve

## Remarks

### Heating:

Because of the unavoidable self heating effects of the electrical current, any loads of more than 3 Amperes connected to the unit can influence the control behavior and temperature accuracy in a negative way.

## Dimensions

All dimensions in mm

