OPENMOVE

User Guide

ENGLISH 06
ESPAÑOL 13
FRANÇAIS 20
DEUTSCH 27
POLSKI 34
ITALIANO 41
PORTUGUÊS 48
NEDERLAND 55
S P У C C K 62
И Й 한국어 69
日本語 76
ภาษาไทย 83
简体中文 90

02



Multifunction Button
Botón multifunción
Bouton Multifonction
Multifunktionstaste
Przycisk wielofunkcyjny
Tasto Multifunzione


Microphone 1
Micrófono 1
Microphone 1
Mikrofon 1
Mikrofon 1
Microfono 1
Microphone 2
Micrófono 2
Microphone 2
Mikrofon 2
Mikrofon 2
Microfono 2
LED Indicator
Indicador LED
Indicateur LED
LED-Anzeige
Wskaźnik LED
Indicatore LED
Volume+ / Power Button
Volumen+ / Encendido
Bouton Volume+ / Alimentation
Lautstärke+ / Ein/Aus
Głośność+/ Włącznik
Volume+ / Power Button
USB-C Charging Port
USB-C
CâbleUSB-C inclus USB-C Ladekabel auf Kabla ładującego USB-C USB-C incluso
Volume- Button
Volumen- Bouton
Volume -
Lautstärke-
Głośność-
Volume-

04



Multifunction Button
Botão Multifunções
Multifunctionele knop
МНОГОФУНКЦИОНАЛЬНАЯ КНОПКА
다기능 버튼
マルチファンクションボタン
多功能键
ปุ่มมัลติฟังก์ชั่นสำหรับควบคุมเพลงและคุยโทรศัพท์


Microphone 1
Microfone 1
Microfoon 1
Микрофона 1
마이크1
マイク1
麦克风1
ไมโครโฟนตัวที่ 1
LED Indicator
Indicador LED
LED Indicator
LED индикатор
Светодиодная индикация
LED 표시
LED インジケータ
LED指示灯
ไฟ LED แสดงสถานะต่างๆของหูฟัง
USB-C Charging Port
Cabo de carga USB-C
USB-C kabel
зарядки USB-C
USB C 타입
USB-C
USB-C充电口
USB-C
Microphone 2
Microfone 2
Microfoon 2
Микрофон 2
Μικρόφωνο 2
마이크2
マイク2
麦克风2
ไมโครโฟนตัวที่ 2
สำหรับรับเสียงพูดขณะคุยโทรศัพท์
Volume+ / Power Button
Volume+ / Ligado
Volume + / Macht Knop
КНОПКА УВЕЛИЧЕНИЯ
Γκροχή ηλεκτρικού ρεύματος
볼륨업/파워버
電源ボタン
音量+键 /开关键
ปุ่ม เปิด/ปิด เครื่อง
Volume- Button
Volume-
Volume - knop
КНОПКА ВКЛЮЧЕНИЯ
КНОПКА УМЕНЬШЕНИЯ ГРОМКОСТИ
볼륨다운버튼
ボリュームボタン
音量-键
ปุ่ม เพิ่ม/ลด ระดับเสียง

ENGLISH

How to Set Up OpenMove

1. Charge

Charge the headphones with the included USB-C charging cable. The LED

2. Pair

Begin with your headphones powered off. Enter pairing mode by pressing and holding volume+ until Audrey says “pairing” and the LED indicator flashes red and blue.

3. Connect

Open your device’s Bluetooth® menu and select “OpenMove by AfterShokz.” Audrey will say “connected” and the LED indicator will flash blue one time.

Let us take care of you! Protect your headphones against defects.
Make sure to register your OpenMove at
Aftershokz.com



(A) Multifunction Button



(C) Volume- Button

(B) Volume+ / Power Button

(D) Earplugs

Multifunction Button (A)

Function	Action	Prompt / “Audrey Says™”
Play / pause music	Click once	One beep
Skip to next song	Double-click while music is playing	One beep
Skip to previous song	Triple-click while music is playing	One beep
Switch language	Double-click while on pairing	“English/中文/ 日本語/한국어”
Answer call	Click once	Two beeps
End call	Click once	One beep
Answer call waiting and hang up on current caller	Press and hold for 2 seconds	One beep
Reject a call	Press and hold for 2 seconds	Two beeps
Activate device’s voice assistant	Press and hold for 2 seconds	Device beep
Redial last number	Double-click (when idle)	"Redial last number"

Volume+ / Power Button (B); Volume- Button (C)

Function	Action	Prompt / “Audrey Says™”
Power on	Press and hold volume+ for 2 seconds	“Welcome to AfterShokz”
Power off	Press and hold volume+ for 3 seconds	“Power off”
Mute	Press and hold both buttons for 2 seconds while on a call	“Mute on” or “Mute off”
Switch EQ	Press and hold both buttons for 3 seconds while music is playing	“Standard mode / Vocal booster mode / Earplug mode”
Check battery status	Click the volume+ or volume- button while music is paused	“Battery high/Battery medium/ Battery low/Charge me”
Adjust volume	Click the volume+ or volume- button to adjust volume while music is playing	One beep

Specifications

Model number	AS660	Frequency response	20Hz - 20kHz
Speaker type	Bone conduction transducer	Speaker sensitivity	96 ± 3dB

Bluetooth® version	Bluetooth® v5.0	Microphone sensitivity	-40 ± 2dB
Wireless range	10 m	Frequency band	2402 - 2480MHz
Battery	Rechargeable Li-Polymer battery	Battery capacity	135 mAh
Continuous play	Up to 6 hours	Standby time	Up to 10 days
Charge time	2 hours	Charge voltage	5.25V ± 5%
Charge type	USB-C	Speaker impedance	8.0 ± 0.5ohm
Water resistance	IP55	Maximum RF output power	4dBm
Weight	29 g	Warranty	2 years
Compatible profiles	HSP, HFP, A2DP AND AVRCP		

LED Indicator

Solid red	Charging
Solid blue	Charging complete
Flashes red and blue	Pairing mode
Flashes blue	Incoming call
Flashes red every 2 minutes	Low battery

Multipoint Pairing

Multipoint pairing allows OpenMove to be connected to two devices at once, allowing users to seamlessly transition between the two.

1. Begin with your headphones powered off.
2. Press and hold volume+ until Audrey says “pairing” and the LED indicator flashes red and blue.
3. Press and hold the multifunction button and volume+ button for 3 seconds. Audrey says "multipoint enabled".
4. Open your first device's Bluetooth® menu and select "OpenMove by AfterShokz." Audrey says "connected".
5. Turn your headphones off.
6. Re-enter pairing mode by pressing and holding volume+ until Audrey says “pairing” and the LED indicator flashes red and blue.
7. Open your second device's Bluetooth® menu and select "OpenMove by AfterShokz." Audrey says "connected".
8. Turn your headphones off.
9. Turn your headphones on. Your headphones are now connected to both devices. Audrey says "connected" and "device 2 connected".
10. To turn off multipoint pairing: Press and hold the multifunction and volume - buttons for 3 seconds when pairing. Audrey says"multipoint disabled".

More information: bit.ly/aftershokzpairing

How to Reset Your Headphones

1. Begin with your headphones powered off.
2. Enter pairing mode by pressing and holding volume+ until Audrey says “pairing”
   and the LED indicator flashes red and blue.
3. Press and hold the multifunction button, volume+ button and volume- button
   (all three buttons) simultaneously for 3-5 seconds, until you hear two beeps
   or feel vibrations.
4. Turn your headphones off. OpenMove is now reset and can be re-paired
   to your device.

Optional Accessories

Earplugs (D)

Use earplugs with headphones in environments where it is safe to block out ambient noise, such as on a train or airplane.

1. Roll earplugs firmly between fingers and place in ears.
2. To adjust EQ settings for earplugs, press and hold volume+ and volume- buttons
   simultaneously while music is playing. Continue through options until "earplug
   mode."

Manufacturer

AfterShokz LLC

3200 Gracie Kiltz Lane, 4th floor, Austin, TX