PROCEDURE FOR MAKING A EYE SPLICE
TERMINAL IN A CONTROL CABLE

① CUT CABLE TO APPROXIMATE LENGTH

② SLIP ON – SLEEVE

③ FORM LOOP THRU SLEEVE

THIMBLE

CUT SHARP POINTS OFF

④ INSERT THIMBLE IN FORMED LOOP

⑤ SLIDE SLEEVE UP AGAINST THIMBLE

⑥ USE COMPRESSION TOOL

3 1 2

COMPRESSION SEQUENCE

3 1 2

⑦

⑧ COMPLETED CABLE TERMINAL