



N female solderless for
Ecoflex 15 HEATEX
7397

Egnede kabler:
ECOFLEX15 HEATEX



EAN: 5704717005055



7397

Mounting instruction

ECOFLEX® 15 HEATEX

N-Socket, solderless / Art. Nr.: 7352



1



Cut off cable tail right-angled with a small metall saw. The inner conductor has to be kept absolutely round.

2



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.

3



Remove 7 mm of the outer sheath with a knife.

4



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.

5



Remove the copper foil and the dielectric with a knife. The inner conductor must stay absolutely round. Remove burr from sharp edges.

6



Move inner pin into the teflon-isolator. Subsequently, clip inner pin carefully onto the inner conductor. Hint: The inner conductor can be prepared with just a slim film of Vaseline, before attaching the inner pin. This improves the attenuation of intermodulation and prevents corrosion.

7



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 19 mm. A small split should remain visible between clamping nut and connector housing.