



## ECOFLEX10 Clamp 7367P

Egnede kabler:  
ECOFLEX10



EAN: 5704717003525



7367P

# Mounting instruction

**ECOFLEX® 10 / AIRCOM PLUS®**  
N-Connector / Art. Nr.: 7367 / 7367P



**1**



Cut off cable tail right-angled.

**2**



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.

**3**



Remove 6 mm of the outer sheath with a knife.

**4**



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.

**5**



Remove the copper foil and the dielectric with a knife.

**6**



Stick inner pin onto the inner conductor and solder carefully. Put on the Teflon-Isolator. Hint:

Pin 1: 2,8mm Ø AIRCOM PLUS

Pin 2: 3,0mm Ø ECOFLEX 10.

**7**



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain visible between clamping nut and connector housing.

**7367P**



The N-Connector 7367P has a modified press ring for a stronger fastening of the coaxial cable. Mounting the 7367P complies completely to the 7367 installation.