



N female for Aircom
Premium/Ecoflex10
Clamp - 7364

Egnede kabler:
ECOFLEX10



EAN: 5704717003556



7364

Mounting instruction

ECOFLEX® 10 / AIRCOM PLUS®

N-Socket / Art. Nr.: 7364



Cut off cable tail right-angled.



Move the nut, clamping ring and rubber washer over the cable tail. Hint: With a bit of Vaseline the rubber washer can be moved easily over the cable sheath.



Remove 6 mm of the outer sheath with a knife.



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.



Remove the copper foil and the dielectric with a knife.



Stick inner pin onto the inner conductor and solder carefully. Put on the Teflon-Isolator. Hint:

Pin 1: 2,8mm Ø AIRCOM PLUS
Pin 2: 3,0mm Ø ECOFLEX 10.



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain visible between clamping nut and connector housing.