



| Antennas & antenna accessories: |                                                                                            |
|---------------------------------|--------------------------------------------------------------------------------------------|
| 433RUB:                         | High-flex antenna, 433 MHz, 1/4 wave, approx. 4 cm, straight BNC terminal                  |
| 1/4-433:                        | High-flex antenna, 433 MHz, 1/4 wave, approx. 17cm, angled BNC terminal                    |
| 1/4-433S:                       | High-flex antenna, 433 MHz, 1/4 wave, approx. 17cm, straight BNC terminal                  |
| 1/4-433K3 / K5 / K10:           | High-flex antenna, 433 MHz, 1/4 wave, approx. 17cm, 3 / 5 / 10 m of cable and BNC terminal |
| 1/2-433:                        | High-flex antenna, 433 MHz, 1/2 wave, approx. 35cm, angled BNC terminal                    |
| 1/2-869:                        | High-flex antenna, 869 MHz, 1/2 wave, approx. 17cm, angled BNC terminal                    |
| 1/2-433S:                       | High-flex antenna 1/2 wave, approx. 35 cm, straight BNC terminal                           |
| Dip-433K3:                      | Dipole antenna with 3 m of cable, 433 MHz, BNC connector and wall bracket                  |
| Dip-869K3:                      | Dipole antenna with 3m of cable, 869 MHz, BNC connector and wall bracket                   |
| 5/8-433K3 / K5 / K10:           | Steel antenna, 433 MHz, 5/8 wave, approx. 65cm, 3 / 5 / 10 m of cable and BNC terminal     |
| FI:                             | Antenna bracket for fitting on vehicles                                                    |
| VM1:                            | Antenna bracket for fitting on wall                                                        |
| T-BNC:                          | T-shaped BNC terminal                                                                      |
| M802030:                        | FME/FME terminal                                                                           |
| M221110                         | BNC/FME terminal                                                                           |

#### TELE RADIO AB

Sweden, Main office  
Tel. +46 (0)31-748 54 60  
e-mail: info@tele-radio.com

www.tele-radio.com

#### TELE RADIO SVERIGE

Sweden  
Tel. +46 (0)31-724 98 00  
e-mail: sverige@tele-radio.com

#### TELE RADIO OÜ

Estonia  
Tel. +372 44 511 55  
e-mail: m.jyrissoo@tele-radio.com

#### TELE RADIO GmbH

Germany  
Tel. +49 (0)94 51-944 8 550  
e-mail: kontakt@tele-radio-gmbh.de

#### TELE RADIO ASIA

China  
Tel. +86-(0)592-3111168  
e-mail: b.sun@tele-radio.cn

#### TELE RADIO TURKEY

Turkey  
Tel. +90-532 292 4448  
e-mail: c.mevlevioglu@tele-radio.com

#### TELE RADIO LTD

England  
Tel. +44 (0) 1625 509125  
e-mail: sales@teleradiouk.com

#### TELE RADIO LLC

North America & Latin America  
Tel. +1 (305) 459 0763  
e-mail: america@tele-radio.com

#### TELE RADIO BV

Benelux  
Tel. +31-(0)70-419 41 20  
e-mail: info@teleradio.nl

#### TELE RADIO AS

Norway  
Tel. +47-6933 4900  
e-mail: norway@tele-radio.com