




No.	Description	Quantity	No.	Description	Quantity
1	left cover	1	29	Coil spring	1
2	Fixed block	1	30	Coil spring cover	1
3	Overload the thermostat	1	31	right housing	1
4	left housing	1	32	The tighten cap	1
5	handle	1	33	left cover	1
6	Synchronous gear cover	1	34	Long cable	1
7	Synchronous belt	1	35	Window	1
8	Small synchronous gear	1	36	Hose stop	1
9	Synchronous gear	1	37	Short cable	1
10	Insulated shaft	1	38	ST4X12 screw	4
11	Insulation cover	1	39	ST4X12 screw	3
12	Round hole fixed block	1	40	M4X14 screw	3
13	plug	2	41	Line pressing board	1
14	Expansion screws	2	42	ST3X16 screw	9
15	The fixed frame	1	43	insert4.5	3
16	The reversing plate	1	44	Copper insert	2
17	The reversing block	1	45	Into the thread insert	1
18	Mounting bracket	1	46	Wave type of copper	1
19	Supply to hose	1	47	copper	1
20	Hose Reel	1	48	sheath	1
21	Guide plate	1	49	M5X12 screw	1
22	ST4X25 screw	4	50	ST4X16 screw	5
23	Ratchet	1	51	ST4X10 screw	3
24	Intermediate shaft	1	52	ST4X16 screw	2
25	ratchet	1	53	ST4X14 screw	2
26	Tension spring	1	54	ST4X14 screw	2
27	Ratchet rack	1	55	rivet	2
28	Coil spring inside	1			