



SPARE PARTS

Descrizione

TRITURA 200



SPARE PARTS

Descrizione Cospet		TRITURA 200
N°	CODICE	DESCRIPTION
1	HC32GF215.01	Cable
3	HC32GF215.03	Upper cover
4	HC32GF215.04	Cable base cover
6	HC32GF215.06	Bracket
7	HC32GF215.07	Stator
9	HC32GF215.09	Shaft(with Rotor)
10	HC32GF215.10	Auto-Cut
11	HC32GF215.11	Bearing fixer
12	HC32GF215.12	Centrifugal switch
13	HC32GF215.13	Centrifugal switch cover
14A	HC32GF215.14A	Capacitor
14B	HC32GF215.14B	Start Capacitor
16	HC32GF215.16	Motor frame
17	HC32GF215.17	Lubricant
19	HC32GF215.19	Bearing bracket
20A	HC32GF215.20A	Upper bearing
20B	HC32GF215.20B	Lower bearing
21	HC32GF215.21	Mechanical Seal
23	HC32GF215.23	Mechanical Seal bracket
24	HC32GF215.24	Oil seal bush
25	HC32GF215.25	Oil seal
26	HC32GF215.26	Casing
27	HC32GF215.27	Impeller
36	HC32GF215.36	Flange
39	HC32GF215.39	Radial cutter
40	HC32GF215.40	Cutter ring
41	HC32GF215.41	Handle
46	HC32GF215.46	Impeller key
55	HC32GF215.55	Oil Plug
56	HC32GF215F.56	Floater