


***Raychem***<sup>®</sup>


---

**CE20-01**







**CE20-03**

---




**A**


\*CE20-03 only

**B****C****D****E****G****B****C**





HWAT-L  
 HWAT-M  
 HWAT-R → CE25-01



Aluminium




FS-A-2X  
 FS-B-2X  
 FS-C-2X  
 FS-C10-2X  
 GM-2X  
 FroStop Black  
 FroStop Green  
 LC2-10-CR  
 FreezeGard-W32  
 FreezeGard-W52  
 R-ETL-A





HWAT-L/-M

4




FS-A-2X  
FS-B-2X  
FS-C-2X  
FS-C10-2X  
GM-2X


FroStop Black  
FroStop Green  
LC2-10-CR  
FreezeGard-W32  
FreezeGard-W52

HWAT-L  
HWAT-M  
ETL-A


5




6




7




8




9



10




CE20-03 → 20




CE20-01

11→19

11



12






HWAT-L/-M

13

13



HWAT-L/-M



FS-A-2X  
FS-B-2X  
FS-C-2X


FS-C10-2X  
GM-2X  
FroStop Black

FroStop Green  
HWAT-L  
HWAT-M


14

14





40 mm







15












23




24




25




26



27





**België / Belgique**

Tyco Thermal Controls  
Romeinse Straat 14  
3001 Leuven  
Tel. 016 21 35 02  
Fax 016 21 36 04

**Česká Republika**

Tyco Thermal Controls Czech, s.r.o.  
Pražská 636  
252 41 Dolní Břežany  
Tel. +420 241 911 911  
Fax +420 241 911 100

**Danmark**

Tyco Thermal Controls Nordic AB  
Flöjelbergsgatan 20B  
SE-431 37 Mölndal  
Tel. 70 11 04 00  
Fax 70 11 04 01

**Deutschland**

Tyco Thermal Controls GmbH  
Englerstraße 11  
69126 Heidelberg  
Tel. 0800 1818205  
Fax 0800 1818204

**España**

Tyco Thermal Controls N.V.  
Ctra. De la Coruña, km. 23,500  
Edificio ECU I  
28290 Las Rozas, Madrid  
Tel. (34) 902 125 307  
Fax (34) 91 640 29 90

**France**

Tyco Thermal Controls SAS  
B.P. 90738  
95004 Cergy-Pontoise Cedex  
Tél. 0800 906045  
Fax 0800 906003

**Italia**

Tyco Thermal Controls SPA  
Centro Direzionale Milanofiori  
Palazzo F1  
20090 Assago, Milano  
Tel. 02 5776151  
Fax 02 577615528

**Nederland**

Tyco Thermal Controls b.v.  
Van Heuven Goedhartlaan 121  
1181 KK Amstelveen  
Tel. 0800 0224978  
Fax 0800 0224993

**Norge**

Tyco Thermal Controls Norway AS  
Postboks 146  
1441 Drøbak  
Tel. 66 81 79 90  
Fax 66 80 83 92

**Österreich**

Tyco Thermal Controls  
Office Wien  
Brown-Boveri Strasse 6/14  
2351 Wiener Neudorf  
Tel. 0 22 36 86 00 77  
Fax 0 22 36 86 00 77-5

**Polska**

Tyco Thermal Controls Polska Sp. z o.o.  
ul. Cybernetyki 19  
02-677 Warszawa  
Tel. +48 22 331 29 50  
Fax +48 22 331 29 51

**Schweiz / Suisse**

Tyco Thermal Controls N.V.  
Office Baar  
Haldenstrasse 5  
Postfach 2724  
6342 Baar  
Tel. 041 766 30 80  
Fax 041 766 30 81

**Suomi**

Tyco Thermal Controls Nordic AB  
Flöjelbergsgatan 20B  
SE-431 37 Mölndal  
Puh. 0800 11 67 99  
Faksi 0800 11 86 74

**Sverige**

Tyco Thermal Controls Nordic AB  
Flöjelbergsgatan 20B  
SE-431 37 Mölndal  
Tel. 020-210 100  
Fax 031-335 58 99

**Türkiye**

SAMM Dış Ticaret A.Ş.  
Yeniyl Sk. Etap İş Merkezi C Blok No: 10  
Kat: 6  
34722 Acıbadem - Kadıköy  
İSTANBUL  
Tel: +90-216-325 61 62 (Pbx)  
Faks: +90-216-325 22 24

**United Kingdom**

Tyco Thermal Controls (UK) Ltd  
3 Rutherford Road,  
Stephenson Industrial Estate  
Washington, Tyne & Wear  
NE37 3HX  
Tel. 0800 969013  
Fax: 0800 968624

**РОССИЯ и другие страны СНГ**

ООО « Тайко Термал Контролс »  
141407, Московская обл., г. Химки  
ул. Панфилова, 19, 11 этаж,  
Деловой Центр Кантри Парк  
Тел. +7 (495) 926 18 85  
Факс +7 (495) 926 18 86

**tyco****Thermal Controls****www.tycothermal.com**