
SNV-18 Low vibration straight needle scaler



1: Needles 45564 (18) 2: S-18-02 Front 3: S-18-03 Forward Spring 4: S-18-04 Needle Holder * 5: S-18-05 Housing 6: S-18-06 Housing Cover 7: S-18-07 Screw 8: S-18-08 Balance 9: S-18-09 Seal Ring 10: S-18-10 Balance Extension 11: S-18-11 Seal Ring 12: S-18-12 Piston 13: S-18-13 Piston Ring 14: S-18-14 Damper 15: S-18-15 Limit Ring 16: S-18-16 Valve 17: S-18-17 Lever 18: S-18-18 Valve Stem 19: S-18-19 O-ring (2) 20: S-18-20 Rear 21: S-18-21 Spring 22: S-18-22 Pin 23: S-18-23 Rear Spring 24: S-18-24 O-ring

* For Non-Spark Needles a special needle holder is required, see separate documentation for S-18-04BC

IPT Technologies AB, Stockholm, Sweden