

Enøk/ Econ Midi 2000



CE UK IP44 IK10

220-240V, 50/60Hz (Sensor: 50Hz)

0,5 – 1,0 mm² 8 mm 1,5 – 2,5 mm² 12 mm		
NO: Kan kun installeres og vedlikeholdes av en registrert installasjonsvirksomhet. DK: Må kun installeres og vedlikeholdes af uddannet elektriker. SE: Skall installeras och underhållas av behörig elektriker. EN: Only to be installed and maintained by an authorized electrician. FR: Doit être installé et maintenu par un électricien qualifié. NL: Mag alleen geïnstalleerd en onderhouden worden door een bevoegde elektricien. DE: Dieses Produkt darf nur durch autorisiertes Personal (z.B. Elektro-Installateur) angeschlossen, in Betrieb genommen und gewartet werden. FI: Asentaa ja huoltaa saa vain valtuutettu sähköasentaja NO: Skru av strømmen før montering. DK: Sluk for strømmen inden montering. SE: Stäng av strømmen innan montering. EN: Turn off power before installing. FR: Couper le courant avant l'installation. NL: Stroom uitschakelen voor u het toestel installeert. DE: Vor Installationsarbeiten den Strom abschalten. FI: Sammuta virta ennen kytkemistä		

NORWAY
SG Armaturen AS

Skytterheia 25
N-4790 Lillesand

Tel: +47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no

SWEDEN

SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FINLAND

SG Armaturen Oy
Tel: +358 02 07 30 39 60
info@sg-oy.fi
www.sg-oy.fi

DENMARK

SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk

UNITED KINGDOM

SG Lighting LTD
Tel: +47 37 50 03 00
info@sglighting.co.uk
www.sglighting.co.uk

FRANCE

SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net

BENELUX

SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net

GERMANY

SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de

INTERNATIONAL

SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com


Rev: 14.12.2020


Sensor Wireless

HC028V/RF + HC023RF




230V, 50Hz






Switched power		400W
Microwave frequency		5.8GHz+/-75MHz
Microwave power		<0.2mW
RF frequency		433/868/315/915 MHz



Max 9m
Max 4m





Max 6m
Max 12m




HC028V/RF
 Sensor
 Tx →
 Rx ←

HC023RF
 Slave
 Rx ←





< 30m



< 100m



	1	2	
I	●	●	100%
II	●	○	75%
III	○	●	50%
IV	○	○	10%




	1	2	3	
I	●	●	●	5s
II	●	●	○	30s
III	●	○	○	1min
IV	●	○	○	5min
V	○	●	○	10min
VI	○	○	●	20min
VII	○	○	○	30min



	1	2	
I	●	●	Disable
II	●	○	50Lux
III	○	●	10Lux
IV	○	○	2Lux



	1	2	3	
I	●	●	●	0s
II	●	●	○	10s
III	●	○	○	1min
IV	●	○	○	5min
V	○	●	○	10min
VI	○	○	●	30min
VII	○	○	○	1h
VIII	○	○	○	+∞



	1	2	
I	●	●	10%
II	●	○	20%
III	○	●	30%
IV	○	○	50%

CORPORATE OFFICE:

SG Armaturen AS
Svåbekk 15
4790 Lillesand
NORGE

Tlf: +47 37 50 03 00
 firmapost@sg-as.no
 www.sg-as.no

BRANCH OFFICE:

SG Lighting SA/NV
 Blokhuisstraat 47
 2800 Mechelen Noord I
 BELGIQUE/BELGIË

Tlf: +32(0) 15 20 72 71
 info.benelux@sglighting.net
 www.sglighting.net

BRANCH OFFICE:

SG Armaturen A/S
 Egebakken 19
 7400 Herning
 DANMARK

Tlf: +45 70 70 72 13
 info@sg-as.dk
 www.sg-as.dk

BRANCH OFFICE:

SG Lighting SA/NV
 73 rue de Saint Mandrier
 83140 Six Fours Les Plages
 FRANCE

Tlf: +33(0) 4 94 93 00 00
 info.france@sglighting.fr
 www.sglighting.net

BRANCH OFFICE:

SG Leuchten GmbH
 Nordstrasse 53
 59399 Olfen
 GERMANY

Tlf: +49 2595 3870 725
 info@sg-leuchten.de
 www.sg-leuchten.de

BRANCH OFFICE:

SG Armaturen AB
 August Barksg. 30B
 421 32 Västra Frölunda
 SVERIGE

Tlf: +46 31 81 71 10
 info@sg-ab.se
 www.sg-ab.se