

Operating instruction (UK)

WRKPRO Work Lamp "SLIM X8"

Item no. 50616150

Intended Use

The product is intended to be used as a mobile inspection light source. It's practical size and function makes it possible to carry in the hand, in a pocket or in a bag. The magnetic function makes it possible to attach the work lamp to any suitable, magnetic surface and thereby giving way for a hands-free operation. The operation of the product requires a rechargeable battery of the type 3,7V 2200mAh (which is included in the product). If you use the product for purposes other than those described above, the product may be damaged. Furthermore, an improper use involves risks such as short-circuits, fire etc. Please read the operating instructions carefully and do not discard them. If you pass the product on to a third party, please hand over these operating instructions as well. This product complies with the applicable National and European legal requirements. The WRKPRO brand name is a trademark owned by Diesella A/S. All rights reserved.

Package Contents

- LED work light
- Rechargeable battery 3,7V 2200mAh Li-Ion
- Charging adaptor and USB cable
- Operating instructions

Explanation of Symbols



An exclamation mark in a triangle indicates important instructions in this operating manual which absolutely **MUST BE OBSERVED**.



The arrow symbol is used when specific tips and information on handling are provided.

Safety Instructions



Please read the operating instructions carefully and pay attention to the safety instructions. We do not cover liability for injuries/material damages resulting from failure to observe the safety instructions and the information in these operating instructions regarding the proper handling of the product. Furthermore, in such cases, the warranty/guarantee of the product will no longer be valid.

a) General

- The product is not a toy. Keep out of the reach of children and pets.
- Do not leave packing materials unattended. It may become a dangerous plaything for children.
- The product is designed for use indoors and outdoors. However, it must not be used in or under water, as this will destroy it.
- Protect the product from extreme temperatures, direct sunlight, strong vibrations and combustible gases, vapors and solvents.
- Never expose the product to mechanical stress.
- If safe operation is no longer possible, take the device out of service and secure it against unintended use. Safe operation is no longer possible, if the product:
 - has visible damage,
 - no longer functions properly,
 - has been stored under adverse ambient conditions for an extended period of time or
 - has been exposed to considerable strain during transport.
- Please handle the product carefully. The product can be damaged if crushed, struck or dropped, even from a low height.
- Do not look directly into the LED light!
- Do not look directly or with optical instruments into the light!
- Maintenance, adjustment and/or repair work may be carried out only by an expert or a specialist workshop ONLY!
- If you have any questions, that are not answered in these operating instructions, please contact our technical customer service or another specialist.
- If the work lamp offers the possibility of changing the battery (directions are found in the section "Inserting batteries, replacing batteries" – then please observe the correct polarity when placing the rechargeable battery into the unit.
- If you are not going to use the device for a while, remove the rechargeable battery to prevent damage from leaking. Leaking or damaged rechargeable batteries can cause acid burns upon contact with the skin. Thus, you should wear protective gloves when handling damaged batteries/rechargeable batteries.
- Keep the rechargeable batteries out of the reach of children. Do not leave batteries lying around, as they may be swallowed by children or pets.
- Replace all the rechargeable batteries at the same time. Mixing old and new rechargeable batteries or mixing different rechargeable batteries in the device may lead to battery leaks and will thus damage the device.
- Do not dismantle rechargeable batteries, do not short-circuit them and do not throw them into fire. Never charge conventional, non-rechargeable batteries. There is a danger of explosion!

Inserting Batteries, Replacing Batteries



- **Please note: This product is pre-installed with a rechargeable battery!**



IMPORTANT NOTICE ABOUT THE BATTERY:

- THE BATTERY OF THIS PRODUCT CANNOT BE CHANGED!
- DO NOT TRY TO DISMANTLE THE PRODUCT – THE WARRANTY WILL BE VOID.

Operating and charging procedure

Operation:

- Turn on the LED inspection lamp by pressing the power switch "⏻".
- 1st push on the on/off switch "⏻" activate the light in low-mode.
- 2nd push on the on/off switch "⏻" activate the light in high-mode.
- 3rd push on the on/off switch "⏻" turns off the work lamp.
- Use the magnetic function (magnet installed in the bottom) to attach the work lamp on any suitable, magnetic surface for a hands-free operation. The angle of the magnet can be adjusted by the 2-stage structure of the bracket.
- Use the built-in belt hook to attach the light to a suitable edge, cord or pocket.

Charging the battery:

- Switch the lamp off before you connect the USB charging.
- Connect the USB cable to the work light and put the charging adaptor into a power switch.
- The battery indicator will start to blink when charging has started. When charging has finished (= the battery is fully charged) the light will stay in constant green color.
- **Please use the provided adaptor and USB cable ONLY! Any non-recommended charger and/or USB cable can lead to a fire and eventually destroy the lamp.**

Care and Cleaning

- Never use abrasive cleaning agents, cleaning alcohol or other chemical solutions, since these could damage the enclosure or even impair operation.
- Use a dry, lint-free cloth to clean the product.

Disposal

a) Product



Electronic devices are recyclable material and do not belong in the household waste. Dispose of the unserviceable product in accordance with the relevant statutory regulations.

Remove any inserted batteries/rechargeable batteries and dispose of them separately from the product.

b) Batteries/rechargeable batteries

As the end user, you are required by law (Battery Ordinance) to return all spent batteries/rechargeable batteries; disposal of them in the household waste is prohibited.



Batteries/rechargeable batteries contain harmful materials and are labelled with the symbol shown to indicate that disposal in the household waste is forbidden. The symbols of the critical heavy metals are: Cd=cadmium, Hg=mercury, Pb=lead (the marking can be seen on the battery/rechargeable battery, e.g. underneath the refuse bin symbol shown on the left).

You can return your used batteries/rechargeable batteries free of charge at the official collection points of your community, in our stores, or at places where batteries or rechargeable batteries are sold. You thereby fulfil your statutory obligations and contribute to the protection of the environment.

Technical Data

LED light source:.....	COB LED
Max. output:.....	500 Lumens
Min. output:.....	280 lumens
Run time:.....	2 – 3,5 hours
Operating voltage:.....	3,7V 2200mAh Li-Ion battery
Charging time:.....	4 hours
Charger:.....	5V DC 1A
Protection class:.....	IP65
Operating/storage conditions:.....	-10° C to 40° C, max. 93% relative humidity, non-condensing
Dimensions:.....	200 x 52 x 34 mm
Weight:.....	213 g

Reservations are made for printing errors and / or errors describing the product

This publication has been made by Diesella A/S, Marsvej 20, DK-6000 Kolding (www.diesella.com).

Publication: 50616150-WRKPRO-SLIM X8-INSTRUCTION_UK_DK

Date: 22-06-2019

Brugervejledning (DK)

WRKPRO arbejdslampe "SLIM X8"

Varenr. 50616150

Anvendelsesformål

Produktet er beregnet til brug som en portabel arbejds-/inspektionslampe. Produktets størrelse og design gør den let at bære i hånden, i en lomme og/eller i en arbejds taske. Den magnetiske funktion gør det muligt at fastgøre lyskilden på en passende magnetisk overflade. Produktet kræver 1 stk. genopladeligt batteri 3,7V 2200mAh Li-Ion (hvilket er inkluderet i produktet). Hvis produktet til andre formål end de ovenfor beskrevne, kan produktet blive beskadiget. U hensigtsmæssig brug vil desuden indebære risici som f.eks. kortslutninger, brand osv. Læs derfor venligst betjeningsvejledningen omhyggeligt og kassér den ikke. Hvis du videregiver produktet til en tredje part, bedes du også overlevere denne brugsanvisning sammen med produktet. Dette produkt overholder gældende nationale og europæiske lovkra v. WRKPRO brandnavnet er et varemærke ejet af Diesella A / S. Alle rettigheder forbeholdes.

Produkt indhold

- LED lyskilde
- Genopladeligt batteri 3,7V 2200mAh Li-Ion (forud installeret)
- Oplader adapter og USB lade kabel
- Brugervejledning

Forklaring af symboler



Udråbstegn I en trekant indikerer nogle meget vigtige instruktioner I denne vejledning, hvilke **SKAL LÆSES IGENNEM**.



Pil symbolet bruges, når der gives specifikke tips og oplysninger om håndtering.

Sikkerheds instruktioner



Læs venligst betjeningsvejledningen omhyggeligt og følg sikkerhedsanvisningerne. Vi dækker ikke ansvar for skader / materielle skader som følge af manglende overholdelse af sikkerhedsinstruktionerne og oplysningerne i denne betjeningsvejledning vedrørende korrekt håndtering af produktet. I sådanne tilfælde vil garantien bortfalde og dermed ikke længere gyl dig.

b) Generelle info

- Produktet er ikke et legetøj. Det skal opbevares utilgængeligt for børn og kæledyr.
- Efterlad ikke emballagen uden opsyn. Det kan blive et farligt legetøj for børn.
- Produktet er designet til indendørs- og udendørs anvendelse. Dog må apparatet ikke anvendes i eller under vand, da dette vil ødelægge produktet.
Beskyt produktet mod ekstreme temperaturer, direkte sollys, stærke vibrationer og brændbare gasser, dampe og opløsningsmidler.
- Udsæt aldrig produktet for mekanisk belastning.
- Hvis en sikker betjening ikke længere er mulig, skal du tage enheden ud af drift og sikre den mod utilsigtet brug. Sikker drift er ikke længere muligt, hvis produktet:
 - Har synlige skader,
 - Ikke længere fungerer korrekt,
 - er blevet opbevaret under ugunstige omgivel sesforhold i længere tid eller
 - har været udsat for betydelig belastning under transporten.
- Håndtér produktet omhyggeligt. Produktet kan blive beskadiget, hvis det knuses, rammes af stød eller falder ned, selv fra en lav højde.
- Kig ikke direkte ind i LED-lyskilden!
- Kig ikke direkte ind i LED-lyskilden med nogen former for optiske instrumenter!
- Vedligeholdelse, justering og / eller reparationsarbejde må kun udføres af en ekspert eller et specialværksted!
- Hvis du har spørgsmål, der ikke besvares i denne betjeningsvejledning, skal du kontakte vores tekniske kundeservice eller en anden specialist.
- Hvis arbejdslampen giver mulighed for udskiftning af batteriet (vejledningen findes i afsnittet "Isæt batterier / udskiftning af batterier") undersøg da venligst den rigtige polaritet, når du sætter det nye genopladelige batteri i enheden.
- Hvis du ikke skal anvende lyskilden i et stykke tid, bør du fjerne det genopladelige batteri (såfremt det er muligt) for at forhindre skade på grund af lækage. Lækage eller beskadigede genopladelige batterier kan forårsage syreforbrændinger ved kontakt med huden. Derfor skal du bære beskyttelseshandsker, når du håndterer beskadigede batterier.
- Opbevar de genopladelige batterier utilgængeligt for børn. Lad ikke batterier ligge tilgængeligt, da de kan blive slugt af børn og/eller kæledyr.
- Udskift alle genopladelige batterier samtidigt. Hvis du blander gamle og nye genopladelige batterier eller blander forskellige genopladelige batterier i enheden, kan det føre til batterilækage og dermed beskadige enheden.
- Afmonter ikke genopladelige batterier, kortslut dem ikke og kast dem ikke i ild. Oplad aldrig konventionelle, ikke-genopladelige batterier. Der er fare for eksplosion!

Isæt batterier / udskiftning af batterier



- BEMÆRK VENLIGST: DETTE PRODUKT HAR FORUD INSTALLERET, GENOPLADELIGT BATTERI!!!



- **VIGTIG BEMÆRKNING OM BATTERIET:**
- **BATTERIET I DETTE PRODUKT KAN IKKE UDSKIFTES!!!**
- FORSØG IKKE AT SKILLE LYSKILDEN AD FOR AT UDSKIFTE BATTERIET – DETTE VIL MEDFØRE AT GARANTIE N BORTFALDER.

Drifts- og opladningsprocedure

Arbejdslys:

- Tænd LED lyskilden ved at trykke på on/off knappen "☰".
- 1. tryk på on/off knappen "☰" aktiverer lyskilden i laveste lys niveau (low-mode)
- 2. tryk på on/off knappen "☰" ændrer lyskilden til højeste lys niveau (high-mode)
- 3. tryk på on/off knappen "☰" slukker lyskilden.
- Brug den magnetisk funktion (magnet installeret i bunden) for at fastgøre arbejdslampen på en passende magnetisk overflade til håndfri betjening. Magnetbeslaget kan justeres i 2 faste trin.
- Brug den indbyggede krog for at fastgøre lyset til en passende kant, ledning eller lomme.

Opladningsprocedure:

- Sluk for lampen inden opladning og tilslut dernæst opladerkablet til arbejdslampen.
- Batteriindikatoren begynder at blinke når opladningen er startet. Når opladningen er fuldført (=batteriet fuldt opladt), forbliver lyset i konstant, blå farve.
- Brug **kun** den medfølgende adapter og USB-kabel! Enhver ikke-anbefalet oplader og/eller USB-kabel kan føre til brand og til sidst ødelægge lampen.

Pleje og rengøring

Brug aldrig slibende rengøringsmidler, rensebenzin eller andre kemiske opløsninger, da disse kan beskadige kabinettet og/eller forringe driften.

- Brug altid en tør, fnugfri klud til at rengøre produktet.

Bortskaffelse

c) Produkt



Elektroniske produkter er genanvendeligt materiale og tilhører ikke husholdningsaffaldet. Bortskaf det ikke-brugbare produkt i overensstemmelse med de relevante lovbestemmelser.

Fjern eventuelle isatte batterier / genopladelige batterier og kassér dem separat fra produktet.

d) Batterier/genopladelige batterier

Som slutbruger er du påkrævet ved lov (Batteri forordningen) at returnere alle brugte batterier / genopladelige batterier; bortskaffelse af dem i husholdningsaffald er forbudt.



Batterier / genopladelige batterier indeholder skadelige materialer og er mærket med det viste symbol for at angive, at bortskaffelse i husholdningsaffaldet er forbudt. Symbolerne for de kritiske tungmetaller er: Cd = cadmium, Hg = kviksølv, Pb = bly (markeringen kan ses på batteriet / genopladeligt batteri, f.eks. Under affaldssymbolet vist til venstre).

Du kan returnere dine brugte batterier / genopladelige batterier gratis til de officielle indsamlingssteder i dit lokale, i vores butikker eller på steder, hvor batterier eller genopladelige batterier sælges. Dermed opfylder du dine lovbestemte forpligtelser og bidrager til beskyttelse af miljøet.

Tekniske Data

LED lyskilde: COB LED
Max. output: 500 Lumens
Min. output: 280 Lumens
Batteri levetid: 2 – 3,5 timer
Driftsspænding: 3,7V 2200mAh Li-Ion batteri
Opladetid: 4 timer
Oplader: 5V DC 1A
Beskyttelsesklasse: IP65
Drifts- og opbevaringsforhold -10° C to 40° C, max. 93% relativ fugtighed, ikke-kondenserende
Produkt størrelse: 200 x 52 x 34 mm
Vægt: 213 g

Der tages forbehold for trykfejl og/eller fejlbeskrivelser der vedrører produktet

Denne publikation er udarbejdet af Diesella A/S, Marsvej 20, DK-6000 Kolding (www.diesella.dk).

Publikations nr.: 50616150-WRKPRO- SLIM X8-INSTRUCTION_UK_DK

Dato: 22-06-2019