



for single & double collector⁽²⁾
Mounting dimensions see page 8



Type	Weight kg	Order-No.
KWS	0,480	250 380
KWS/K⁽¹⁾	0,480	252 340

flexible support type, with single collector
for transfer funnels (see page 14)
Mounting dimensions see page 24



If you are going to use the flexible towing arm in system with curves please contact us.

Type	Weight kg	Order-No. for all types
KFMLN für SKN	1,170	259 506

Spare parts

Powerail

Type	KBSL	KSL
	Order-No.	Order-No.
Joint cap, 150 mm for plug-in joint and bolted joint	257 921	257 921
Stiffener clamp, 50 mm	–	258 797
Stiffener clamp of stainless steel	–	258 812
Bolted joint splice w/hardware plug in joint, max. 100 A	259 274	259 274
Bolted joint 40 - 200 A	258 796	258 796
Adapter for new/old style Powerail (for old KSL)	258 822	258 822

Collector

Type	KBSL & KSL	
	SKR	SKN(K)
	Order-No.	Order-No.
Carbon brush phase, incl. brush holder (lateral)	257 600	254 890
Carbon brush upper fifth pole, incl. brush holder	257 600	254 891
Carbon brush ground , incl. brush holder (lateral)	257 601	254 892
Carbon pressure spring, standard (ca. 5 N)	258 758	258 757
Carbon pressure spring, reinforced (ca. 8,5 N)	258 761	258 760
Throat part, straigh runs (SKN)	–	254 893
Throat part, for curves (SKN/K)	–	254 894
Glider plate	–	–
Trolley wheel (below)	–	254 895
Guide roller (above)	–	254 903
Connecting strap for double collectors	258 379	258 379
Connecting bar for double collectors	258 430	258 431
Attachment clamp KWZL	–	254 897
Attachment clamp KWZ	250 310	–
Cleaning brushes complet set (2 pieces)	–	252 851

⁽¹⁾ Stainless steel

⁽²⁾ In case of installing 2 Powerail systems in parallel use one towing arm each per collector unit.