

European Version





Scandinavian Version



Door directions with left handle version

The handle with the RFID
reader function points to
« the left »



Door directions with right handle version

The handle with the RFID
reader function points to
« the right »



European Version



Scandinavian Version

