

# Advice to users of Trelleborg food hoses

# **Before you start using your Trelleborg food hose:**

Before first use, you should proceed as follows.

- Fill hose with hot water (+ 70 °C to + 80 °C).
  - Keep water inside for minimum 12 hours.
- Then, clean hose using any of the following cleaning processes.

# **Advice for cleaning processes:**

Hot water	Steam
CITERDIAL - LACTADIAL - ALCODIAL - VENDANGE VINITRELL - SUPERVRAC AL EC - TRELLVAC AL EC	
90°C maximum	110°C during maximum 10 minutes
ALIKLER G2 - ALIKLER D - MILLESIME - TRELLVIN	
95°C maximum	130°C during 30 minutes

## **Chemicals**

Nitric acid (HNO3) or product with additional nitric acid.

Maximum concentration: 0.1 % at 85 °C

3 % at room temperature

Chlorine (CI) or product with additional chlorine.

Maximum concentration: 1 % at maximum 70°C

Sodium hydroxide (NaOH) or product with additional

sodium hydroxide.

Maximum concentration: 2 % from 60 °C to 80 °C

5 % at room temperature

Hydrogen peroxide (H2O2) or product with additional

hydrogen peroxide.

Maximum concentration: 3 % at room temperature MILLESIME only: 1.5 % at maximum 85 °C

Every cleaning cycle must be immediately followed by a complete rinse.

### Storage:

Keep away from (sun) light and heat. Only use pierced plugs when needed.

**△** Stagnation:

With ALCODIAL only.

On not use high pressure cleaning systems to wash inside the hose.