

Model Number

NJ5-18GM-N-10M

Features

- · Comfort series
- 5 mm flush •
- Usable up to SIL2 acc. to IEC 61508 •

Accessories

BF 18 Mounting flange, 18 mm EXG-18 Quick mounting bracket with dead stop


Technical Data General specifications Switching element function NAMUR, NC Rated operating distance 5 mm s_n Installation flush NAMUR Output polarity Assured operating distance Reduction factor r_{Al} sa 0 ... 4.05 mm 0.21 Reduction factor r_{Cu} 0.18 Reduction factor r₃₀₄ 0.63 Nominal ratings Nominal voltage 8 V 5 ... 25 V Operating voltage UB Switching frequency 0 ... 500 Hz Hysteresis н 3% Current consumption Measuring plate not detected \geq 3 mA Measuring plate detected $\leq 1 \text{ mA}$ Ambient conditions Ambient temperature -25 ... 100 °C (-13 ... 212 °F) **Mechanical specifications** Connection type cable PVC , 10 m Core cross-section 0.75 mm² Stainless steel 1.4305 / AISI 303 Housing material Sensing face PBT Degree of protection IP67 Cable > 10 x cable diameter Bending radius General information Use in the hazardous area see instruction manuals Category 1G; 2G; 1D Compliance with standards and directives Standard conformity EN 60947-5-6:2000 NAMUR IEC 60947-5-6:1999 Standards EN 60947-5-2:2007 IEC 60947-5-2:2007 Approvals and certificates

UL approval


CSA approval CCC approval

Dimensions

cULus Listed, General Purpose cCSAus Listed, General Purpose CCC approval / marking not required for products rated ≤36 V



Electrical Connection



Pepperl+Fuchs Group www.pepperl-fuchs.com

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



PEPPERL+FUCHS

| ATEX 1G | |
|---|---|
| Instruction | Manual electrical apparatus for hazardous areas |
| Device category 1G | for use in hazardous areas with gas, vapour and mist |
| EC-Type Examination Certificate | PTB 00 ATEX 2048 X |
| CE marking | CE 0102 |
| ATEX marking | € II 1G Ex ia IIC T6T1 Ga |
| Directive conformity | 94/9/EG |
| Standards | EN 60079-0:2012, EN 60079-11:2012, EN 60079-26:2007 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions |
| Appropriate type | NJ 5-18GM-N |
| Effective internal capacitance C _i | \leq 70 nF ; a cable length of 10 m is considered. |
| Effective internal inductance Li | \leq 50 μ H ; a cable length of 10 m is considered. |
| General | The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! |
| | Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration. |
| Ambient temperature | The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate. Note: Use the temperature table for category 1 !!! The 20 % reduction in accordance with EN 1127-1:2007 has already been accounted for in the temperature table for category 1. |
| Installation, commissioning | Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related appara- tus and according to the proof of intrinsic safety. The associated apparatus must satisfy the requirements of category ia. Due to the possible danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation of the power supply and signal circuit is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met. |
| Maintenance | No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible. |
| Special conditions | |
| Protection from mechanical danger | When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing. |
| Electrostatic charge | Electrostatic charges on the metal housing components must be avoided. Danger- ous electrostatic charges on the metal housing components can be avoided by incor- porating these components in the equipotential bonding. |

2

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



Inductive sensor

ATEX 2G

Instruction

Device category 2G EC-Type Examination Certificate CE marking

ATEX marking Directive conformity Standards

Appropriate type Effective internal capacitance C_i Effective internal inductance L_i General

Ambient temperature

Installation, commissioning

Maintenance

Special conditions

Protection from mechanical danger

Electrostatic charge

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X ($E_{\rm D102}$

II 1G Ex ia IIC T6...T1 Ga
94/9/EG
EN 60079-0:2012, EN 60079-11:2012
Ignition protection "Intrinsic safety"

Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions NJ 5-18GM-N...

 \leq 70 nF ; a cable length of 10 m is considered.

 \leq 50 μH ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces

by the mentioned certification authority. If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



ATEX 1D

Instruction

Device category 1D EC-Type Examination Certificate CE marking

ATEX marking Directive conformity Standards

Appropriate type Effective internal capacitance Ci Effective internal inductance Li General

Maximum housing surface temperature

Installation, commissioning

Maintenance

Special conditions Electrostatic charge for use in hazardous areas with combustible dust ZELM 03 ATEX 0128 X €0102

(Ex) II 1D Ex iaD 20 T 108 °C (226.4 °F)

94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions

NJ 5-18GM-N...

 \leq 70 nF ; a cable length of 10 m is considered.

 \leq 50 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

NJ5-18GM-N-10M

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related appara-tus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 und Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding. The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

