





## **Model Number**

FJ7-N

## **Features**

• 7 mm flush

# General specifications

Switching element function		NAMUR, NC
Rated operating distance	s <sub>n</sub>	7 mm
Installation		flush
Output polarity		NAMUR
Assured operating distance	sa	0 5.67 mm
Reduction factor r <sub>Al</sub>		0.4
Reduction factor r <sub>Cu</sub>		0.3
Reduction factor r <sub>304</sub>		0.85

## Nominal ratings

Nominal voltage	Uo	8.2 V (R <sub>i</sub> approx. 1 kΩ)
Operating voltage	UB	5 25 V
Switching frequency	f	0 200 Hz
Hysteresis	Н	typ. %
Current consumption		

Measuring plate not detected ≥ 3 mA

Measuring plate detected ≤ 1 mA

Switching state indicator LED, yellow

# Functional safety related parameters

MTTF <sub>d</sub>	4080 a
Mission Time (T <sub>M</sub> )	20 a
Diagnostic Coverage (DC)	0 %

# Ambient conditions

Ambient temperature -25 ... 100 °C (-13 ... 212 °F)

## Mechanical specifications

Connection type cable PUR, 2 m
Core cross-section 0.34 mm<sup>2</sup>
Housing material brass, zinc plated
Sensing face POM
Degree of protection IP67

# Degree of protection General information

Use in the hazardous area see instruction manuals Category 2G; 3G

## Compliance with standards and directives

Standard conformity

NAMUR EN 60947-5-6:2000 Standards EN 60947-5-2:2007 IEC 60947-5-2:2007


## Approvals and certificates

FM approval


Control drawing 116-0165F

CCC approval CCC approval / marking not required for products rated ≤36 V

## **Dimensions**



## **Electrical Connection**



#### ATEX 2G

Instruction

## Device category 2G

EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity

Standards

Appropriate type

Effective internal capacitance  $\,C_{i}\,$  Effective internal inductance  $\,L_{i}\,$ 

General

Ambient temperature

Installation, Comissioning

Maintenance

#### Specific conditions

Protection from mechanical danger

Electrostatic charging

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2032 X  $\mbox{\bf C}\ \mbox{\bf 6}\ \mbox{\bf 0}102$ 

II 2G Ex ia IIC T6 Gb

#### 94/9/FG

EN 60079-0:2009, EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions FJ7-N...

≤ 65 nF; a cable length of 10 m is considered.

 $\leq$  220  $\mu H$ ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to!

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20  $^{\circ}\text{C}$  the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

PEPPERL+FUCHS

#### ATEX 3G (nL)

Note

#### Instruction

Device category 3G (nL)

CE marking

ATEX marking Directive conformity Standard conformity

 $\label{eq:continuous_equation} \begin{tabular}{ll} Effective internal inductance $L_i$ \\ \end{tabular}$ 

General

Installation, Comissioning

#### Maintenance

## Specific conditions

Maximum permissible ambient temperature  $T_{Umax}$  at Ui = 20 V for Pi=34 mW, Ii=25 mA, T6 for Pi=34 mW, Ii=25 mA, T5 for Pi=34 mW, Ii=25 mA, T4-T1 for Pi=64 mW, Ii=25 mA, T6 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T5 for Pi=64 mW, Ii=25 mA, T4-T1 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T6 for Pi=169 mW, Ii=52 mA, T5 for Pi=169 mW, Ii=52 mA, T5-T1 for Pi=242 mW, Ii=76 mA, T6 for Pi=242 mW, Ii=76 mA, T5 for Pi=242 mW, Ii=76 mA, T5-T1 for Pi=242 mW, Ii=76 mA, T5-T1

Protection from UV light

Protection of the connection cable

Protection from mechanical danger

Electrostatic charging

Connection parts

This instruction is only valid for products according to EN 60079-15:2005, valid until 01-May-2013

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist **C 6** 0102

⟨ II 3G Ex nL IIC T6 X

94/9/EG

EN 60079-15:2005 Ignition protection category "n" Use is restricted to the following stated conditions

 $\leq 65~\text{nF}$  ; a cable length of 10 m is considered.

 $\leq$  220  $\mu H$  ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with an energy-limited circuit, which satisfies the requirements of IEC 60079-15. The explosion group complies with the connected, supplying, power limiting circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

73 °C (163.4 °F) 88 °C (190.4 °F) 100 °C (212 °F) 73 °C (163.4 °F) 88 °C (190.4 °F) 100 °C (212 °F) 62 °C (143.6 °F) 77 °C (170.6 °F) 81 °C (177.8 °F) 54 °C (129.2 °F) 63 °C (145.4 °F) 63 °C (145.4 °F)

The sensor must not be exposed to **ANY FORM** of mechanical danger. When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of IP20 is achieved, in accordance with IEC 60529.

#### ATEX 3G (ic)

Instruction

#### Device category 3G (ic)

Certificate of Compliance

CE marking

ATEX marking

Directive conformity

Standards

Effective internal capacitance  $C_i$ 

Effective internal inductance Li

General

Installation, Comissioning

#### Maintenance

## Specific conditions

Maximum permissible ambient temperature  $T_{Umax}$  at Ui = 20 V

for Pi=34 mW, Ii=25 mA, T6
for Pi=34 mW, Ii=25 mA, T5
for Pi=34 mW, Ii=25 mA, T4-T1
for Pi=64 mW, Ii=25 mA, T6
for Pi=64 mW, Ii=25 mA, T5
for Pi=64 mW, Ii=25 mA, T5
for Pi=69 mW, Ii=25 mA, T6
for Pi=169 mW, Ii=52 mA, T6
for Pi=169 mW, Ii=52 mA, T5
for Pi=169 mW, Ii=52 mA, T4-T1
for Pi=242 mW, Ii=76 mA, T6
for Pi=242 mW, Ii=76 mA, T5
for Pi=242 mW, Ii=76 mA, T5
for Pi=242 mW, Ii=76 mA, T5
for Pi=242 mW, Ii=76 mA, T4-T1
Protection from mechanical danger

Electrostatic charging

Connection parts

#### Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist

PF 13 CERT 2895 X

(€

⟨ II 3G Ex ic IIC T6 Gc

94/9/EG

EN 60079-0:2009, EN 60079-11:2012 Ignition protection category "ic" Use is restricted to the following stated conditions

≤ 65 nF; a cable length of 10 m is considered.

 $\leq$  220  $\mu H$  ; A cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be observed!

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The sensor must only be operated with energy-limited circuits, which satisfy the requirements of IEC 60079-11. The explosion group depends on the connected and energy-limited supply circuit.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

73 °C (163.4 °F) 88 °C (190.4 °F) 100 °C (212 °F) 73 °C (163.4 °F) 88 °C (190.4 °F) 100 °C (212 °F) 62 °C (143.6 °F) 77 °C (170.6 °F) 81 °C (177.8 °F) 54 °C (129.2 °F) 63 °C (145.4 °F) 63 °C (145.4 °F)

The sensor must not be mechanically damaged.

When used in the temperature range below -20 °C the sensor should be protected from knocks by the provision of an additional housing.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

The connection parts are to be installed, such that a minimum protection class of

IP20 is achieved, in accordance with IEC 60529.

Note This instruction is only valid for products according to EN 50281-1-1, valid until 30-September-2008

Note the ex-marking on the sensor or on the enclosed adhesive label

Manual electrical apparatus for hazardous areas Instruction

Device category 3D

for use in hazardous areas with non-conducting combustible dust CE marking **C**€0102

ATEX marking ⟨ II 3D IP67 T 109 °C (228.2 °F) X

94/9/EG Directive conformity Standards EN 50281-1-1 Protection via housing

Use is restricted to the following stated conditions

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The data stated in the data sheet are restricted by this operating instruction! The special conditions must be adhered to! Laws and/or regulations and standards governing the use or intended usage goal must be observed.

Installation, Comissioning Maintenance

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

Specific conditions

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance Minimum series resistance Ry

with the following list. This can also be assured by using a switch amplifier.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are

Maximum heating (Temperature rise) Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resistance Rv.

9 K at U\_Bmax=9 V, R\_V=562  $\Omega$ 

using an amplifier in accordance with 9 K

EN 60947-5-6

Electrostatic charging

The sensor must not be mechanically damaged. Protection from mechanical danger

Protection of the connection cable The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the mechanical housing components can be avoided by incorporating these in the equipotential bonding.

## ATEX 3D (tD)

Note This instruction is only valid for products according to EN 61241-0:2006 and EN 61241-1:2004

Note the ex-marking on the sensor or on the enclosed adhesive label

Instruction Manual electrical apparatus for hazardous areas

Device category 3D

for use in hazardous areas with non-conducting combustible dust < € |

CE marking

ATEX marking ⟨ II 3D Ex tD A22 IP67 T80°C X

Directive conformity 94/9/FG

Standards EN 61241-0:2006, EN 61241-1:2004

Protection via housing "tD"

Use is restricted to the following stated conditions

General The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

The maximum surface temperature has been determined in accordance with method A without a dust layer on the equipment.

The data stated in the data sheet are restricted by this operating instruction!

The special conditions must be adhered to!

Installation, Comissioning Laws and/or regulations and standards governing the use or intended usage goal must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Maintenance

Repairs to these apparatus are not possible.

tance Rv.

61 °C (141.8 °F)

Specific conditions Minimum series resistance R<sub>V</sub>

A minimum series resistance RV is to be provided between the power supply voltage and the proximity switch in accordance

Values can be obtained from the following list, depending on the max. operating voltage Ub max and the minimum series resis-

with the following list. This can also be assured by using a switch amplifier.

Maximum operating voltage U<sub>Bmax</sub> The maximum permissible operating voltage UBmax must be restricted to the values given in the following list. Tolerances are not permitted

Maximum permissible ambient tempera-

ture  $T_{Umax}$ at U $_{\rm Bmax}$ =9 V, R $_{\rm V}$ =562  $\Omega$ 

using an amplifier in accordance with  $\,$  61 °C (141.8 °F)

EN 60947-5-6

Protection from mechanical danger

Protection from UV light

Electrostatic charging

Protection of the connection cable

The sensor must not be exposed to ANY FORM of mechanical danger.

The sensor and the connection cable must be protected from damaging UV-radiation. This can be achieved when the sensor is

used in internal areas.

The connection cable must be prevented from being subjected to tension and torsional loading.

Electrostatic charges must be avoided on the mechanical housing components. Dangerous electrostatic charges on the

mechanical housing components can be avoided by incorporating these in the equipotential bonding.