



Datasheet

Article number: 70008467 Designation: KG10.T103/33.KS51V Description: Switchgear

Sample image

	947-3, VDE 0660 Teil 107						
Rated insulation voltage U							
		Va	oltage (V) AC / D 690 AC	С			
Rated uninterrupted curre	nt lu/lth		090 AC				
Current (A)	Ambient temperature (°C)	Peak temperature ((°C) additional re	quirements			
20	50		55 Ambient ter	nperature +50°C o	during 24 hours v	vith peaks up to +55°C	
Rated operational current	le				-		
Utilization category				Vo	ltage (V)		Current (A
AC-15					20 - 240		
AC-15				3	80 - 440		
Rated operational power							
Utilization category		Voltage (V)	N	lo. of phases		No. of poles	Power (kW
AC-3		220 - 240		3		3	2,2
AC-3		380 - 440		3		3	3,7
AC-3		660 - 690		3		3	3,7
AC-3		220 - 240		1		2	1,1
AC-3		380 - 440		1		2	1,5
AC-23A		220 - 240		3		3	
AC-23A AC-23A		380 - 440		3		3	5,5
		660 - 690				3	5,5
AC-23A		220 - 240		1			1,5
AC-23A Max Fuse Rating IEC		380 - 440		1		2	2,2
Fuse characteristic					No. of Fu	1000	Current (A
gG					NO. 01 FL	1	2
•						I	2
UL60947-4-1 , UL50	08						
Nominal Voltage							
		Vo	oltage (V) AC / D	С			
	-		300 AC				
Rated insulation voltage U	Ji		h (1) 10 (D	2			
		VC	oltage (V) AC / D	C C			
Rated thermal current			300 AC				
	Current	(A)		Ambient tempera	turo (°C) Additio	nal Taxt	
tatod merindi odirent	Current	, ,		Ambient tempera		nal Text	
		(A) 20		Ambient tempera	ture (°C) Additio 0 - 40	nal Text	
Horsepower rating		, ,			0 - 40		Ambient temperature [°
Horsepower rating Across-the-Line Motor Star		, ,	Voltage (V)	No. of phases	0 - 40 No. of poles	Power (HP)	
Horsepower rating Across-the-Line Motor Star DOL		, ,	Voltage (V) 110 - 120		0 - 40 No. of poles 2		4
Horsepower rating Across-the-Line Motor Star DOL DOL		, ,	Voltage (V) 110 - 120 220 - 240	No. of phases 1 1	0 - 40 No. of poles 2 2	Power (HP) 0,50 1	4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277	No. of phases 1 1	0 - 40 No. of poles 2 2 2 2	Power (HP) 0,50 1 1	4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120	No. of phases 1 1 1 3	0 - 40 No. of poles 2 2 2 2 3	Power (HP) 0,50 1 1 1	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277	No. of phases 1 1	0 - 40 No. of poles 2 2 2 2	Power (HP) 0,50 1 1	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120	No. of phases 1 1 1 3	0 - 40 No. of poles 2 2 2 2 3	Power (HP) 0,50 1 1 1	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL Pilot duty rating code Duty Code		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120	No. of phases 1 1 1 3	0 - 40 No. of poles 2 2 2 2 3	Power (HP) 0,50 1 1 1	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300		, ,	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120	No. of phases 1 1 1 3	0 - 40 No. of poles 2 2 2 2 3	Power (HP) 0,50 1 1 1	44444444
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating	ting	, ,	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120	No. of phases 1 1 1 3	0 - 40 No. of poles 2 2 2 2 3	Power (HP) 0,50 1 1 1	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating Conditions of acceptability	ting	20	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3	0-40 No. of poles 2 2 2 3 3	Power (HP) 0,50 1 1 1 2	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DUL DUL DUL DUL DUL Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable	ting	20	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3	0-40 No. of poles 2 2 2 3 3	Power (HP) 0,50 1 1 1 2	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DOL DUT Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable	ting , , e for use on circuits capable of delive Temperature rating (20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0-40 No. of poles 2 2 2 3 3	Power (HP) 0,50 1 1 1 2	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DOL DIt Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire	ting , , e for use on circuits capable of delive	20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 1 2	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions	ting , , e for use on circuits capable of delive Temperature rating (20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	4 4 4 4
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DUL DUL DUL Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions Markings	ting , , e for use on circuits capable of delive Temperature rating (20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	444444444444444444444444444444444444444
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DOL DUT Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions Markings	ting , , e for use on circuits capable of delive Temperature rating (20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	444444444444444444444444444444444444444
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL DOL DOL DOL DOL DOL	ting , e for use on circuits capable of delive Temperature rating (60 -	20 ring not more than 5kA rms	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240	No. of phases 1 1 3 3 9	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	44444444
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions Markings Break all lines. For use on a flat surface of General Use	ting , e for use on circuits capable of delive <i>Temperature rating (</i> 60 - f a type 1 enclosure.	20 ring not more than 5kA rms 7C) 75	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240 symmetrical am	No. of phases 1 1 3 3 yperes, 300V ac m	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions Markings Break all lines. For use on a flat surface of General Use AC / DC Voi	ting ting for use on circuits capable of delive Temperature rating (60 - f a type 1 enclosure. Itage (V) Current (A)	20 ring not more than 5kA rms PC) 75 No. of phases	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240 symmetrical am	No. of phases 1 1 3 3 peres, 300V ac m Cu	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	44 44
Horsepower rating Across-the-Line Motor Star DOL DOL DOL DOL DOL Pilot duty rating code Duty Code A300 SCCR / Max. fuse rating Conditions of acceptability These devices are suitable Temp. rating of wire Connecting instructions Markings Break all lines. For use on a flat surface of General Use	ting , e for use on circuits capable of delive <i>Temperature rating (</i> 60 - f a type 1 enclosure.	20 ring not more than 5kA rms 7C) 75	Voltage (V) 110 - 120 220 - 240 277 - 277 110 - 120 220 - 240 symmetrical am	No. of phases 1 1 3 3 yperes, 300V ac m	0 - 40 No. of poles 2 2 3 3 ax. when protect rrrent (A) Text	Power (HP) 0,50 1 1 2 ed by Class J fuses.	Ambient temperature [*C 4 4 4 4 4 4 4




General Use								
AC / DC Voltage (V)	Current (A)	No. of phases	No. of pol	es			No. of contacts	s in series
AC 300	20	3		3				1
General Information								
Text								
- The operating handle and position in	dicating means to be use	d with these manual mo	tor controllers show	uld be provided fro	om the manufact	urer, or the operatin	g handle and position indicati	ng means
to be used should have been previou	isly evaluated in combina	tion with the manual mot	tor controllers.					
- When intended for use as a motor di	sconnector the device sh	all be provided with a me	thod of being locke	ed in the OFF-posi	tion.			
CSA								
Nominal Voltage								
Nominal Voltage			Voltage (V) AC / I					
			300 AC					
Rated insulation voltage Ui			300 A0					
Rated modulation voltage of			Voltage (V) AC / I	00				
			300 AC					
Rated thermal current			000 /10					
	Current	(A)		Ambient tempera	ature (°C) Additic	nal Text		
		20			0-40			
Horsepower rating								
Across-the-Line Motor Starting			Voltage (V)	No. of phases	No. of poles	Power (HP)	Ambient temper	rature [°C]
DOL			110 - 120	1	2	0,50		40
DOL			220 - 240	1	2	1		40
DOL			277 - 277	1	2	1		40
DOL			110 - 120	3	3	1		40
DOL			220 - 240	3	3	2		40
Pilot duty rating code								
Duty Code								
A300								
Temp. rating of wire								
	Temperature rating (Cı	urrent (A) Text			
		75						
General Use								
AC / DC Voltage (V)	Current (A)	No. of phases	No. of pol				No. of contacts	
AC 277	20	1		1				1
AC 277	20	3		3				1
GENERAL TECHNICAL INFO	RMATION							
Size of conductor								
					Cross section	n (mm²) or		
composition of conductor		lax. value	No. of co	onductor per termi			Material of the wire	
solid wire	Min.				1 0.5mm ²		Copper	
solid wire	Min.				2 0.5mm ²		Copper	
flexible wire	Min.				1 0.75mm ²		Copper	
flexible wire	Min.				2 0.75mm ²		Copper	
flexible wire	Max.				1 AWG 12		Copper	
flexible wire	Max.				1 2.5mm ²		Copper	
Single-core or stranded wire	Max.				1 AWG 12		Copper	
Single-core or stranded wire	Max.				1 2.5mm ²		Copper	
flexible wire with ferrule according to					1 2.5mm ²		Copper	
flexible wire with ferrule according to					1 0.5mm ²		Copper	
flexible wire with ferrule according to	DIN 46228 Min.				2 0.5mm ²		Copper	
Stripping length								
		L	.ength (mm)					
			Ē					
			8	-				
Recommended screw driver								
Type of screw driver			Value					
Cross Screwdriver			PH1					
Slot screwdriver according to DIN 526	64		0,8x4					
Tightening torque of screws								
		tightening	torque (Nm)				tightening tor	que (lb-in)
			0,60					5
Approbations								
Specification								Marking
540								EAE
EAC								
								CE
CE marking								して
								UK
UK Directives								UK CA
								~
								Ð
CSA C.22.2 No.14								
General Information								
Text								
- Do not lubricate or treat contacts.								
- Switches may only be mounted, con	nected and set into opera	tion by qualified persons	according to the a	ccepted rules of te	echnology.			
, , ,		, , , , , , , , , , , , , , , , , , , ,						

General Information

Text	
- Use copper wire	only. Do not coat the wire end with tin.
	actory fitted jumper links are tightened during production. Take care during installation to ensure factory fitted links are not lost by undoing both sides of linked terminals. After wiring, ws must be tightened to recommended torque specifications.
- After installation	of the switches the spacings between the terminals must be sufficient to fulfill the requirement of the applicable standards.
Waste Electrical 8	& Electronic Equipment (WEEE)
Picture name	Description
X	Do not throw in the trash as care must be taken to ensure environmentally sound disposal and recycling. Please either use an environmentally friendly waste disposal company; return to the supplier for disposal; or return direct to the manufacturer, Kraus & Naimer. You can find local Kraus & Naimer offices at www.krausnaimer.com
Proposition 65	
Picture name	Description
\wedge	WARNING: This product can expose you to chemicals including nickel and lead, which is known to the State of California to cause cancer. For more information go to www.P65Warnings.ca.gov.

Classification Contact: Rigid contact bridge
Classification Contact Mat: Silver
Classification Terminal: Screw terminal





$\begin{array}{c|c} & & & & & & \\ & & & & & \\ &$



Face plate

