

Technical Data General specifications Switching element function

Installation

Output polarity

Nominal ratings Installation conditions

Nominal voltage

Hysteresis

Switching frequency

Current consumption Measuring plate not detected

MTTF_d Mission Time (T_M) Diagnostic Coverage (DC)

Ambient conditions

Housing material

Degree of protection General information Use in the hazardous area

Standard conformity NAMUR

Approvals and certificates

Sensing face

Category

Standards

FM approval Control drawing

UL approval

CSA approval

CCC approval

Dimensions

Ambient temperature

Mechanical specifications Connection type Core cross-section

Measuring plate detected Functional safety related parameters

Compliance with standards and directives

А В

С F

FM

APPROVED

Rated operating distance

Assured operating distance Reduction factor r_{Al}

Reduction factor r_{Cu}

Reduction factor r₃₀₄

NAMUR, NC

0 ... 12.15 mm 0.4

15 mm

non-flush

NAMUR

0.3

0.85

18 mm

30 mm 45 mm

90 mm

> 3 mA

≤ 1 mA

4560 a 20 a 0 %

8.2 V (R_i approx. 1 kΩ) 0 ... 100 Hz

-25 ... 100 °C (-13 ... 212 °F)

see instruction manuals

EN 60947-5-6:2000 IEC 60947-5-6:1999 EN 60947-5-2:2007

IEC 60947-5-2:2007

M30 x 1.5

cULus Listed, General Purpose

cCSAus Listed, General Purpose

CCC approval / marking not required for products rated ≤36 V

34.5 40

116-0165F

1 ... 5 typ. 3 %

cable PVC , 2 m

0.75 mm²

PBT

PBT

IP68

2G: 1D

s_n

Sa

Uo

Н



Model Number

NJ15-30GK-N

Features

- 15 mm non-flush
- Usable up to SIL2 acc. to IEC 61508 •

Accessories

BF 30

Mounting flange, 30 mm

Date of issue: 2014-08-01 106486_eng.xml Release date: 2014-08-01 12:33

Refer to "General Notes Relating to Pepperl+Fuchs Product Information"			
Pepperl+Fuchs Group	USA: +1 330 486 0001	Ge	
www.pepperl-fuchs.com	fa-info@us.pepperl-fuchs.com	fa-i	

JSA: +1 330 486 0001	
fo@us.pepperl-fuchs.com	fa

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com

Electrical Connection

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

Л

36

ΒN

ΒU

L+


Т



1

NJ15-30GK-N

Installation Conditions



Refer to "General Notes Relating to Pepperl+Fuchs Product Information".

Pepperl+Fuchs Group USA: +1 www.pepperl-fuchs.com fa-info@us.p Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com



2

Inductive sensor

ATEX 2G

Instruction

Device category 2G EC-Type Examination Certificate CE marking

ATEX marking

Directive conformity Standards

Appropriate type

 $\begin{array}{l} \mbox{Effective internal capacitance } C_i \\ \mbox{Effective internal inductance } L_i \\ \mbox{General} \end{array}$

Ambient temperature

Installation, Comissioning

Maintenance

Specific conditions

Protection from mechanical danger

Manual electrical apparatus for hazardous areas

for use in hazardous areas with gas, vapour and mist PTB 00 ATEX 2048 X ($E_{\rm D102}$

⟨€x⟩ II 2G Ex ia IIC T6 Gb

94/9/EG EN 60079-0:2009, EN 60079-11:2012 Ignition protection "Intrinsic safety" Use is restricted to the following stated conditions NJ 15-30GK...-N...

 \leq 140 nF ; a cable length of 10 m is considered. \leq 100 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual. The EC-Type Examination Certificate has to be observed. The special conditions must be adhered to! Directive 94/9/EG and hence also EC-Type Examination Certificates apply in general only to the use of electrical apparatus under atmospheric conditions. The use in ambient temperatures of > 60 °C was tested with regard to hot surfaces by the mentioned certification authority.

If the equipment is not used under atmospheric conditions, a reduction of the permissible minimum ignition energies may have to be taken into consideration.

The temperature ranges, according to temperature class, are given in the EC-Type Examination Certificate.

Laws and/or regulations and standards governing the use or intended usage goal must be observed. The intrinsic safety is only assured in connection with an appropriate related apparatus and according to the proof of intrinsic safety.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

When used in the temperature range below -20 $^{\circ}\text{C}$ the sensor should be protected from knocks by the provision of an additional housing.



ATEX 1D

Instruction

Device category 1D EC-Type Examination Certificate CE marking

ATEX marking Directive conformity Standards

Appropriate type Effective internal capacitance Ci Effective internal inductance Li General

Maximum housing surface temperature

Installation, Comissioning

Maintenance

Specific conditions

Electrostatic charging

Manual electrical apparatus for hazardous areas

for use in hazardous areas with combustible dust ZELM 03 ATEX 0128 X €0102

⟨ Ex⟩ II 1D Ex iaD 20 T 108 °C (226.4 °F)

94/9/EG IEC 61241-11:2002: draft; prEN61241-0:2002 type of protection intrinsic safety "iD" Use is restricted to the following stated conditions

NJ 15-30GK...-N...

 \leq 140 nF ; a cable length of 10 m is considered. \leq 100 μ H ; a cable length of 10 m is considered.

The apparatus has to be operated according to the appropriate data in the data sheet and in this instruction manual.

NJ15-30GK-N

The EC-Type Examination Certificate has to be observed.

The special conditions must be adhered to!

The maximum surface temperature of the housing is given in the EC-Type Examination Certificate

Laws and/or regulations and standards governing the use or intended usage goal must be observed.

The intrinsic safety is only assured in connection with an appropriate related appara-tus and according to the proof of intrinsic safety.

The associated apparatus must satisfy at least the requirements of category ia IIB or iaD. Because of the possibility of the danger of ignition, which can arise due to faults and/or transient currents in the equipotential bonding system, galvanic isolation in the power supply and signal circuits is preferable. Associated apparatus without electrical isolation must only be used if the appropriate requirements of IEC 60079-14 are met.

The intrinsically safe circuit has to be protected against influences due to lightning. When used in the isolating wall between Zone 20 and Zone 21 or Zone 21 and Zone 22 the sensor must not be exposed to any mechanical danger and must be sealed in such a way, that the protective function of the isolating wall is not impaired. The applicable directives and standards must be observed.

No changes can be made to apparatus, which are operated in hazardous areas. Repairs to these apparatus are not possible.

The connection cables are to be laid in accordance with EN 50281-1-2 and must not normally be subjected to chaffing during use.

Germany: +49 621 776 4411 fa-info@de.pepperl-fuchs.com fa-info@us.pepperl-fuchs.com

Singapore: +65 6779 9091 fa-info@sg.pepperl-fuchs.com

